


## OLED Wiring diagram






Expansion board port	3.3V	SDA	SCL	NC	GND	NC
OLED	3.3V	SDA	SCL	NC	GND	NC

## RGB bar/cooling Fan Wiring diagram




Expansion board	3Pin port	2Pin port	
	RGB bar	Cooling fan	

## Power button Wiring diagram



Jetson carrier board	PWR BTN	GND	LED+	LED-
Power button	Blue line	Black line	Red line	Black line
2Pin port	Blue-black		Red-black	



Jetson carrier board	SYS RST	GND	
Reset button Red line		Black line	
New The AUTO ON and DIG interference the Leave and the Lea			

Note: The AUTO ON and DIS interfaces on the Jetson carrier board require the use of jumper caps for short circuiting.