

1. Install nodejs and npm

sudo apt-get update sudo apt install nodejs npm

However, the version installed directly with the above command is relatively low. Subsequent errors may be reported during the installation of the jupyterlab plugin. We can check the version with the following command, we must have node version 12.3.0 or higher.

node -v npm -v

2. Install n module

We need to use this module to update or specify the version of node installed.

npm install -g n

Clear the npm cache: npm cache clean -f

Install n module: npm install -g n

Install the official stable version: n stable
Install the latest official version: n latest
Install a specified version: n 11.6.0
Check the installed node version: n
View the current node version: node -v
Delete the specified version: n rm 7.5.0

Input following command to install latest version node.

sudo n latest

After installation is complete, input command node -v to check version number.

Input following command:

<mark>sudo n</mark>

Input following command to restart Jetson NANO.

sudo reboot

o node/15.0.1 Use up/down arrow keys to select a version, return key to install, d to delete, q to quit



```
jetson@jetson-desktop:~$ node -v
v15.0.1
jetson@jetson-desktop:~$ npm -v
7.0.3
```

3. Install jupyterlab

3.1 Install some dependent package
(Ignore the warning, execute it for multiple failures)
sudo pip3 install jupyter jupyterlab
sudo jupyter labextension install @jupyter-widgets/jupyterlab-manager
sudo jupyter labextension install @jupyterlab/statusbar

3.2 Generate the corresponding configuration file jupyter lab --generate-config

Input notebook password: jupyter notebook password

You must remember this password.

3.3 Set up boot self-starting jupyterlab, create_jupyter_service.py file Transfer create_jupyter_service.py file into Jetson NANO system by WinSCP. pyhon3 create_jupyter_service.py

Move the generated service file to the system service. sudo mv nano_jupyter.service /etc/systemd/system/nano_jupyter.service

Enable this service.

sudo systemctl enable nano jupyter.service

Start up this service.

sudo systemctl start nano_jupyter.service

4. Install jetcam

Input following command:
git clone https://github.com/NVIDIA-AI-IOT/jetcam
cd jetcam
sudo python3 setup.py install

More Detail, please check https://github.com/NVIDIA-AI-IOT/jetcam