
Flashed SD re-read disk

This tutorial is for the TF card that has been written with an image, but cannot be recognized by the computer and cannot be rewritten.

Generally, the win7 system cannot recognize the burned Ubuntu system drive letter. Win10 can use SDformat software to format.

1. Check whether the computer can recognize the TF card.

Right-click the computer and select "Manage", select Disk Management, and find out whether there is a removable disk with the size of the TF card.



2.Deleting partition

You can use the partition assistant to delete all the partitions of the TF card, about 10 of them, and then format the disk, so that the two software can recognize the drive letter again, and then you can burn the image again.

(You can also use the disk management to select all partitions. Note that you should not only delete the partitions below, but also delete the small extra partitions in the list above. After deleting, create a new partition and format it into fat32 to correctly recognize the drive letter)

Finally, according to the tutorial for writing the image, you can write the image system to the TF card normally.