

OpenClaw Application: Camera

Ensure that OpenClaw has been configured.

Interact via the TUI terminal:


```
openclaw tui
```

Enter the interactive command:

A camera has been connected to the mainboard. Please use this camera to take a photo and place the resulting image on the mainboard's desktop.



We can move the photo to a location that is convenient to access (for example, to the `~/temp/` directory within the Docker environment, and then open it using an image viewer).



Properties x

Size 640 × 480 pixels

Type JPEG image

File Size 43.2 kB

Folder [temp](#)

Aperture

Exposure

Focal Length

ISO

Metering

Camera

Date

Time