

OpenClaw Application: AI Programming (Peripherals & GPIO Control)

Ensure that OpenClaw has been configured.

Interact via the TUI terminal:

```
openclaw tui
```

Enter your interactive command:

I have connected an LED to GPIO17; this LED requires a high-level signal to be driven. Please turn on this LED.