Camera preview

Camera preview
1. Enter Docker
2. Camera preview screen

1. Enter Docker

```
sh ~/ros_melodic.sh
```



2. Camera preview screen

After entering Docker, we need to enter the user directory: just enter the cd command!

```
python3 ~/CameraPreview.py
```


Activities
Unknown
Jan 15 16:28
MAXN
en
root@yahboom: /
jetson@yahboom:~$ sh ~/ros_melodic.sh
access control disabled, clients can connect from any host
ROS_DOCKER: ROS1-melodic
root@yahboom:/# python3 ~/CameraPreview.py
NVIDIA
Jetson Support Forums
L4T-README
CameraPreview
FPS:30.16
(x=612, y=89) ~ R:33 G:43 B:53