Network Configuration

Network Configuration

1. WiFi Mode
    1.1. Connect to WiFi
    1.2. Check WiFi Information
    1.3. Set a Static IP
2. Hotspot Mode
    2.1. Create a Hotspot
    2.2. Hotspot Information


The WiFi and hotspot modes require a wireless network card. Check whether the wireless network card and antenna are installed before making the following settings!

```
It is recommended to switch networks by connecting a display screen. Once the network is switched to a new network, the system needs to enable network sharing again for the new network before VNC remote control can be performed
```


1. WiFi Mode

1.1. Connect to WiFi


Select the menu option in the upper right corner of the system desktop → Wi- Fi Settings:





Select the WiFi to be connected: if the WiFi signal is very weak, check whether the antenna is not installed or the environment has poor signal



After entering the password, click Connect:









1.2. Check WiFi Information

Click the settings icon of the connected WiFi:



In the terminal, use the following command to view the IP addresses of all networks: `enP8p1s0` is the wired interface and `wlP1p1s0` is the WiFi interface

```
ifconfig
```




1.3. Set a Static IP

Click the settings icon of the connected WiFi to modify the IPv4 options:


Address: enter the IP address to be fixed, which needs to be within the assignable IP address range

Netmask: enter 255.255.255.0

Gateway: enter the default gateway address of the WiFi



After completion, reconnect the WiFi to apply the configuration:




2. Hotspot Mode

The wireless network card needs to support hotspot before the hotspot mode can be enabled.

```
Configure the hotspot mode on the desktop system. The hotspot will be
automatically closed after the system restarts. Users who need it can look up the
tutorial on starting the hotspot automatically at boot on Ubuntu 22.04 by
themselves
```

2.1. Create a Hotspot

Enter the WiFi settings and select `Turn On Wi-Fi Hotspot...`





2.2. Hotspot Information

Hotspot name: Jetson_Orin_Hot (customizable)

Hotspot password: 12345678 (customizable)

Default IP of the hotspot mode: 10.42.0.1




Activities
Settings
Jan 10 14:59
MAXN
Settings
Wi-Fi
Wi-Fi
Network
Bluetooth
Background
Appearance
Notifications
Search
Multitasking
Applications
Privacy
Online Accounts
Sharing
Sound
Power
Displays
Mouse & Touchpad
Airplane Mode
Disables Wi-Fi, Bluetooth and mobile broadband
Wi-Fi Hotspot Active
Mobile devices can scan the QR code to connect.
Turn Off Hotspot...
Network Name
Jetson_Orin_Hot
Security type
WPA
Password
12345678