SSH Remote Login

SSH Remote Login


1. MobaXterm
2. MobaXterm Installation
    2.1. Download MobaXterm
    2.2. Install MobaXterm
3. Using MobaXterm
4. MobaXterm: SSH Remote

1. MobaXterm

MobaXterm is a powerful remote tool that integrates remote tools such as SSH, VNC, and FTP.


2. MobaXterm Installation

Official website: https://mobaxterm.mobatek.net/




2.1. Download MobaXterm

Select the free version to download:




Select the installation version to download:




2.2. Install MobaXterm


Extract the archive downloaded from the official website, and open the `MobaXterm_installer_24.4.msi` file to install:




Accept the agreement:




Select the software installation location: the default location is recommended




Start the installation:






Complete the installation:



3. Using MobaXterm

Find the `MobaXterm` icon on the desktop and open it:







4. MobaXterm: SSH Remote

Select `Session` → `SSH`: enter the remote device IP and username


```
Jetson mainboard default information:
Username: jetson
Password: yahboom
```

Note: when you log in over SSH with MobaXterm, it automatically opens an SFTP session in the sidebar.






Enter the user password: the session window does not display the password when it is entered. Press Enter after entering it!



Save the password: it is recommended not to save



Complete the SSH remote login:

