QR code recognition

QR code recognition

1. Install dependencies
2. Create a QR code
3. Parse the QR code
    3.1. The USB camera
    3.2. The CSI camera


FAQ

'PIL.Image' has no attribute 'Resampling'

A QR code (Quick Response Code) is a matrix barcode composed of squares that can be used to store various information.

1. Install dependencies

```
sudo apt install libzbar-dev -y
sudo pip3 install qrcode pyzbar --break-system-packages
```




2. Create a QR code

```
cd ~/qr_code_recognition
```

```
python3 qrcode_create.py
```

After running the command, enter the information hidden in the QR code: the generated image is located in the /home/jetson/qr_code_recognition/figures folder




3. Parse the QR code

3.1. The USB camera

```
cd ~/qr_code_recognition
```


```
python3 qrcode_parsing_usb.py
```



3.2. The CSI camera

```
cd ~/qr_code_recognition
```

```
python3 qrcode_parsing_csi.py
```



FAQ

'PIL.Image' has no attribute 'Resampling'

```
sudo pip3 install --upgrade pillow
```