OpenClaw Application: Camera

Ensure that openclaw has been configured.

Interact via the TUI terminal:


```
openclaw tui
```

Enter the interactive command:

> A camera has already been plugged into the mainboard. Please use this camera to take a photo, and put the captured image on the desktop of the mainboard.



We can move the photo to a convenient place to open it (for example, the `~/temp/` directory of the docker version, and then open it with an image viewer)


100%
camera_photo.jpg
Properties
Size 640 × 480 pixels
Type JPEG image
File Size 43.2 kB
Folder temp
Aperture
Exposure
Focal Length
ISO
Metering
Camera
Date
Time