# OpenClaw Application: AI Programming (Peripheral & GPIO Control)

Ensure that openclaw has been configured.

Interact via the TUI terminal:

```
openclaw tui
```

Enter the interactive command.

I have connected an LED to GPIO17, and this light needs to be driven by a high level. Please light up this LED.