
GPIO reading

GPIO reading

1. GPIO pin diagram
2. Run the program
3. Program effect

1. GPIO pin diagram

GPIO.BOARD pin 12 corresponds to GPIO.BCM pin 18:



2. Run the program

```
cd ~/jetson-gpio/samples
```

```
export JETSON_MODEL_NAME=JETSON_ORIN_NX
```

```
python3 simple_input.py
```

3. Program effect

Use a Dupont wire to connect GPIO.BOARD pin 12 to the GND and 3.3V pins on the mainboard, and test reading the high and low levels:

Note: Do not connect the pins incorrectly or cause a short circuit, as a mistake may damage the mainboard hardware!

