
# Serial communication


**Serial communication**

1. GPIO pin diagram
2. Serial port test
    2.1. Install cutecom
    2.2. Use cutecom
3. Experiment effect


## 1. GPIO pin diagram


GPIO.BOARD pin 8 corresponds to GPIO.BCM 14, GPIO.BOARD pin 10 corresponds to GPIO.BCM 15:




## 2. Serial port test

### 2.1. Install cutecom


```
sudo apt update
sudo apt install cutecom -y
```




## 2.2. Use cutecom

Start `cutecom` in the terminal:

```
cutecom
```



# 3. Experiment effect

Use a jumper cap or a Dupont wire to short-circuit the GPIO.BOARD 8 pin and the GPIO.BOARD 10 pin.

Use `cutecom` to open the `/dev/ttyTHS1` serial port: enter the data to be sent on the serial port in `Input`, the upper window shows the data sent by the `/dev/ttyTHS1` port, and the lower window shows the data received by `/dev/ttyTHS1`:

**Note: Do not connect the pins incorrectly or cause a short circuit, as a mistake may damage the mainboard hardware!**

