## 16.sudo free password

16.sudo free password

Open the terminal, enter the following command, find the %sudo line, as shown in the figure below.

Change the last ALL to NOPASSWD:ALL

sudo visudo

```
# Allow members of group sudo to execute any command %sudo or ALL=(ALL) NOPASSWD:ALL

# See sudoers(5) for more information on "#include" directives:

# Zone
#includedir /etc/sudoers.d
```

Then press "Ctrl+S" to save, and then press Ctrl+X to exit.

After restarting the system, you do not need to enter the password again when you enter sudo again to obtain temporary administrator rights.