

OpenClaw Common CLI Commands

OpenClaw Common CLI Commands

1. Course Content
 - Course Overview
2. Initial Configuration
 - 2.1 `configure` — Configuration Wizard
 - 2.2 View the OpenClaw Version
 - 2.3 View Help for All Available Commands
3. Gateway Management
4. Model Management
 - 4.1 View the Model List and Status
 - 4.2 Set the Default Model
5. Skills and Plugin Management
 - 5.1 Basic Skills Operations
 - 5.2 Plugin Management
6. Configuration, Logs, and Other Useful Commands
 - 6.1 Viewing Logs
 - 6.2 Session Management
 - 6.3 Communication Channel Management

1. Course Content

Course Overview

OpenClaw CLI is the command-line management tool provided by the OpenClaw robot system. This course introduces the most frequently used CLI commands.

2. Initial Configuration

`openclaw onboard` is OpenClaw's interactive onboarding command, which was already covered in the API-KEY configuration chapter:

- Configure the API Key and model connection information
- Set Gateway runtime parameters
- Select the Skills to enable


```
openclaw onboard
```

2.1 `configure` — Configuration Wizard

If there are parameters to adjust after the initial onboarding, you can use the `configure` command to re-enter the interactive configuration interface:

```
openclaw configure
```

OPENCLAW



OpenClaw configure

Existing config detected

```
workspace: ~/.openclaw/workspace
model: bailian/qwen3.6-plus
gateway.mode: local
gateway.port: 18789
gateway.bind: lan
```

2.2 View the OpenClaw Version

```
openclaw --version
```

2.3 View Help for All Available Commands

```
openclaw --help
```

Examples:

```
openclaw models --help
  Show detailed help for the models command.
openclaw channels login --verbose
  Link personal WhatsApp Web and show QR + connection logs.
openclaw message send --target +15555550123 --message "Hi" --json
  Send via your web session and print JSON result.
openclaw gateway --port 18789
  Run the WebSocket Gateway locally.
openclaw --dev gateway
  Run a dev Gateway (isolated state/config) on ws://127.0.0.1:19001.
openclaw gateway --force
  Kill anything bound to the default gateway port, then start it.
openclaw gateway ...
  Gateway control via WebSocket.
openclaw agent --to +15555550123 --message "Run summary" --deliver
  Talk directly to the agent using the Gateway; optionally send the WhatsApp reply.
openclaw message send --channel telegram --target @mychat --message "Hi"
  Send via your Telegram bot.
```

3. Gateway Management

- OpenClaw's gateway is set to start automatically on boot by default

```
openclaw gateway start      # Start the Gateway
openclaw gateway stop       # Stop the Gateway
openclaw gateway restart    # Restart the Gateway
```

- View detailed runtime status of the Gateway, including uptime, connection count, and other information:

```
openclaw gateway status
```

```
Service: systemd (enabled)
File logs: /tmp/openclaw/openclaw-2026-04-28.log
Command: /usr/local/bin/node /home/jetson/.npm-global/lib/node_modules/openclaw/dist/index.js gateway --port 18789
Service file: ~/.config/systemd/user/openclaw-gateway.service
Service env: OPENCRAW_GATEWAY_PORT=18789

Config (cli): ~/.openclaw/openclaw.json
Config (service): ~/.openclaw/openclaw.json

Gateway: bind=lan (0.0.0.0), port=18789 (service args)
Probe target: ws://127.0.0.1:18789
Dashboard: http://192.168.12.28:18789/
Probe note: bind=lan listens on 0.0.0.0 (all interfaces); probing via 127.0.0.1.

Runtime: running (pid 1511, state active, sub running, last exit 0, reason 0)
RPC probe: ok

Listening: *:18789
Troubles: run openclaw status
Troubleshooting: https://docs.openclaw.ai/troubleshooting
```

4. Model Management

4.1 View the Model List and Status

- List all configured models and their basic information:

```
openclaw models list
```

- View the status of all current models, including connection status, latency, availability, etc.:

```
openclaw models status
```

4.2 Set the Default Model

Set a model as the system default model; subsequent conversations will use this model by default:

```
openclaw models set gpt-4o
```

Tip: The model name must exactly match the identifier in the configuration. You can view the available model names with `openclaw models list`.

5. Skills and Plugin Management

5.1 Basic Skills Operations

List all currently installed Skills:

openclaw skills list

✓ ready	arm-pick-and-place	Interface with any ARM 1 v2 component.	openclaw-workspace
✓ ready	comprehensive-task	Complete object pick and place functions using the A comprehensive task that includes garbage sorting, cargo sorting, goods handling between shelves, as well as out-of-stock inspection and restocking. Reference disposal procedures for scenarios involving multiple tasks	openclaw-workspace
✓ ready	robot-navigation	Navigate to the target location on the map with route planning, and support reading and recording map points	openclaw-workspace
✓ ready	visual-functions	Observe the environment and visually track the target	openclaw-workspace
✓ ready	waste-sorting	Observe and sort the garbage cubes into the corresponding trash cans, which is a task related to garbage disposal	openclaw-workspace

5.2 Plugin Management

List all currently installed plugins:

openclaw plugins list

Enable or disable a plugin:

openclaw plugins enable plugin-id

Enable the plugin

openclaw plugins disable plugin-id

Disable the plugin

@openclaw/ feishu	feishu	disabled	global:feishu/index.ts OpenClaw Feishu/Lark channel plugin (community maintained by @mlheng)	2026.3.13
Weixin	openclaw -weixin	loaded	global:openclaw-weixin/index.ts Weixin channel (getUpdates long-poll + sendMessage)	1.0.3
Reply Bridge	reply- bridge	loaded	global:reply-bridge/index.ts Bridge OpenClaw replies to robot_control TTS	1.0.0
Robot Control	robot- control	loaded	global:robot-control/index.ts Robot arm, mobile chassis and visual function control tools	1.0.0

6. Configuration, Logs, and Other Useful Commands

6.1 Viewing Logs

openclaw logs --follow

With the `--follow` parameter, logs are continuously output to the terminal. Press `Ctrl+C` to exit follow mode.

6.2 Session Management

View the list of all currently active sessions:

openclaw sessions

```

Session store: /home/jetson/.openclaw/agents/main/sessions/sessions.json
Sessions listed: 7

```

Kind	Key	Age	Model	Tokens (ctx %)	Flags
direct	agent:main:main	15h ago	qwen3.6-plus	unknown/1000k (?)	system id:eb11227a-e18c-4694-8c45-a56b1bdf5d3d
direct	agent:main:feish...9bf6ae	5d ago	qwen3.6-plus	unknown/1000k (?)	system id:47c556a5-741d-45f2-83b6-88333753d7c6
group	agent:main:openc...wechat	5d ago	qwen3.6-plus	unknown/1000k (?)	id:a55d8c87-acf8-4f16-ad8d-d0c3c1ef54dc
direct	agent:main:openc...wechat	5d ago	qwen3.6-plus	unknown/1000k (?)	system id:a1e9bfe5-3efa-442b-903c-6380de597c97
direct	agent:main:feish...30f803	5d ago	qwen3.6-plus	unknown/1000k (?)	id:6a840c66-7311-4dd5-b010-5fb53ac298bd
direct	agent:main:feish...969539	5d ago	qwen3.6-plus	unknown/1000k (?)	id:4b2f82b0-b67b-497b-bbbb-dd31e97aaf29
direct	agent:main:opena...on-001	6d ago	qwen3.6-plus	unknown/1000k (?)	system id:7912af8c-fd5e-432c-bb37-04dfd808d1e6

6.3 Communication Channel Management

- View all currently available communication channels (Feishu, WeChat, etc.)

```
openclaw channels list
```

Chat channels:

- WhatsApp **default:** not linked, enabled
- Feishu **default:** configured, enabled
- openclaw-weixin **9ae40d3fa0a1-im-bot:** configured, enabled