After the program is downloaded, we start to shake the handle. When the specified time is up, the game ends up displaying the score and the handle vibrates. The score will be displayed when the game is over, and you will need to press the reset button if you need to play again.

Reset button is the restart button

