After the program is downloaded, press the B1 button to start. Move the joystick up to move the red dot up. The red dot cannot touch the obstacle. The score will be displayed when the game is over, and you will need to press the reset button if you need to play again.

B1 is the start button
Reset button is the restart button

