After the program is downloaded, press the B1 button to start. Move the red bar to the left and right to make the red dot catch the red dot above. If the red dot moves to the bottom then the game ends. The score will be displayed when the game is over, and you will need to press the reset button if you need to play again.

B1 is the start button
Reset button is the restart button