After the program is downloaded, press the B1 button to start, move the red dot through the joystick, press the B3 launch bullet to hit the above plane. The score will be displayed when the game is over, and you will need to press the reset button if you need to play again.

B1 is the start button
B3 launch bullet
Reset button is the restart button