Must read before use

After getting the car, you need to set the IP and ROS_DOMAIN_ID. The former is to connect to the agent, and the latter is to interact with the virtual machine. Distributed multi-machine communication

1. Set up the board to connect to wifi

Modify the config_robot.py code in the /home/yahboom directory and find the following parts,

```
robot.set_wifi_config("ssid123", "passwd123")
```

Change ssid123 to your own WiFi name, and change passws123 to the password corresponding to your own WiFi. Save and exit after modification.

2, Set IP

Taking the virtual machine provided by yahboom as an example, query the current IP of the virtual machine and enter in the terminal

```
ifconfig
```

```
ahboom@yahboom-VM:~$ ifconfig
docker0: flags=4099<UP,BROADCAST,MULTICAST> mtu 1500
       inet 172.17.0.1 netmask 255.255.0.0 broadcast 172.17.255.255
       ether 02:42:56:03:dd:d7 txqueuelen 0 (Ethernet)
       RX packets 0 bytes 0 (0.0 B)
       RX errors 0 dropped 0 overruns 0 frame 0
       TX packets 0 bytes 0 (0.0 B)
       TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
ens33: flags=4163<UP,BROADCAST,RUNNING,MULTICAST> mtu 1500
       inet 192.168.2.133 netmask 255.255.255.0 broadcast 192.168.2.255
       inet6 fe80::8757:4696:e812:c3e0 prefixlen 64 scopeid 0x20<link>
       ether 00:0c:29:8d:3e:c2 txqueuelen 1000 (Ethernet)
       RX packets 714352 bytes 412836750 (412.8 MB)
       RX errors 0 dropped 0 overruns 0 frame 0
       TX packets 772866 bytes 69435309 (69.4 MB)
       TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
lo: flags=73<UP,LOOPBACK,RUNNING> mtu 65536
       inet 127.0.0.1 netmask 255.0.0.0
       inet6 ::1 prefixlen 128 scopeid 0x10<host>
       loop txqueuelen 1000 (Local Loopback)
       RX packets 1016004 bytes 378626915 (378.6 MB)
       RX errors 0 dropped 0 overruns 0 frame 0
       TX packets 1016004 bytes 378626915 (378.6 MB)
       TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

As can be seen from the picture, the query here shows that my IP is 192.168.2.133. This is the IP when we start the agent, so we need to set the board to this. IP can connect to the proxy

Use a USB to Type-C cable to connect the board and the virtual machine, and make sure the virtual machine is connected to the board.

```
yahboom@yahboom-VM:-$ lsusb

Bus 002 Device 001: ID 1d6b:0002 Linux Foundation 2.0 root hub

Bus 001 Device 004: ID 1a86:7522 QinHeng Electronics USB Serial

Bus 001 Device 003: ID 0e0f:0002 VMware, Inc. virtual USB Hub

Bus 001 Device 002: ID 0e0f:0003 VMware, Inc. Virtual Mouse

Bus 001 Device 001: ID 1d6b:0001 Linux Foundation 1.1 root hub

yahboom@yahboom-VM:-$
```

Then modify the test_microros.py code in the /home/yahboom directory and find the following parts,

```
robot.set_udp_config([192, 168, 2, 133], 8090)
```

Change [192, 168, 2, 133] here to the ip you queried

Assume that robot.set_ros_domain_id(20) is set to 20, then modify the config_robot.py file as follows,

```
robot.set_ros_domain_id(20)
```

Change the 20 inside to a custom number, which cannot exceed 100.

After the modification is completed, save and exit, and run it in the terminal.

```
cd ~
sudo python3 config_robot.py
```

If the following screen appears, it means the modification is successful. The content in the picture shall be subject to the actual modification. Then you need to restart the board to take effect.

```
yahboom@yahboom-VM:~$ sudo python3 config_robot.py
version: 0.0.3
ssid: Yahboom2
passwd: yahboom890729
ip_addr: 192.168.2.133
ip_port: 8090
car_type: CAR_TYPE_COMPUTER
domain_id: 20
ros_serial_baudrate: 921600
ros_namespace:
servo_offset: 0, 0
motor pid parm: 1.00, 0.20, 0.20
imu yaw pid parm: 1.00, 0.00, 0.20
Please reboot the device to take effect, if you change some device config.
```

2. Virtual machine settings ROS_DOMAIN_ID

Then you also need to set the same ROS_DOMAIN_ID in the ~/.bashrc file of the virtual machine to achieve distributed multi-machine communication between the board and the virtual machine.

Modify the ~/.bashrc file of the virtual machine and enter it in the terminal.

```
sudo gedit .bashrc
```

```
.bashrc
ssid: Yahboom2
passwd: yahboom890729
ip_addr: 192.168.2.133
ip_port: 8888
                                                                  95 # Add an "alert" alias for long running commands. Use like so:
                                                                 96 # sleep 10; alert 97 alias alert='notify-send --urgency=low -i "$([ \$? = 0 ] && echo terminal || echo er
agent: wifi_udp
domain_id: 20
ros_serial_baudrate: 115200
                                                                     (history|tail -n1|sed -e '\''s/^\s*[0-9]\+\s*//;s/[;&|]\s*alert$//'\'')
                                                                  98
servo_offset: 0, 0
pid_parm: 1.00, 0.20, 0.20
yahboom@yahboom-VM:~$ sudo gedit .bashrc
                                                                 100 # You may want to put all your additions into a separate file like 101 # ~/.bash_aliases, instead of adding them here directly.
                                                                 102 # See /usr/share/doc/bash-doc/examples in the bash-doc package.
                                                                 103
(gedit:18234): dconf-WARNING **: 18:25:56.650:
                                                                 104 if [ -f ~/.bash_aliases ]; then
such file or directory)
                                                                 105
                                                                           . ~/.bash_aliases
                                                                 106 fi
(gedit:18234): dconf-MARNING **: 18:25:56.654: such file or directory)
                                                                108# enable programmable completion features (you don't need to enable
109# this, if it's already enabled in /etc/bash.bashrc and /etc/profile
(gedit:18234): dconf-WARNING **: 18:25:56.798:
                                                                 110 # sources /etc/bash.bashrc).
such file or directory)
                                                                111 if ! shopt -oq posix; then
112 if [ -f /usr/share/bash-completion/bash_completion ]; then
(gedit:18234): dconf-WARNING **: 18:25:56.80 such file or directory)
                                                                 113 ./usr/share/bash-completion/bash_completion
114 elif [ -f /etc/bash_completion ]; then
                                                                       . /etc/bash_completion
(gedit:18234): dconf-WARNING **: 18:25:56.80
such file or directory)
                                                                 116
                                                                 117 fi
                                                                 119 export ROS_DOMAIN_ID=20
                                                                 120 есho -е
                                                                                 "MY_DOMAIN_ID: \033[32m$ROS_DOMAIN_ID\033[0m"
                                                                 121
                                                                 122 # >>> fishros initialize >>>
                                                                 123 source /opt/ros/humble/setup.bash
                                                                 124 # <<< fishros initialize <<-
                                                                 125 source /home/yahboom/yahboomcar_ws/install/setup.bash --extend
                                                                 126 #source /home/yahboom/nav2_ws/install/setup.bash --extend
127 source /home/yahboom/gmapping_ws/install/setup.bash --extend
128 source /home/yahboom/imu_ws/install/setup.bash --extend
                                                                 129 #source /home/yahboom/navigation2_ws/install/setup.bash --extend
```

Find ROS_DOMAIN_ID and set it to be consistent with robot.set_ros_domain_id(20) set in 1,

Assume that the setting is 20, fill in 20 here, then save and exit, reopen the terminal, the terminal will display the set ROS_DOMAIN_ID value,



3. Test whether the modification is completed

Enter the following command in the virtual machine terminal to enable the agent:


```
sudo docker run -it --rm -v /dev:/dev -v /dev/shm:/dev/shm --privileged --net=host
microros/micro-ros-agent:humble udp4 --port 8090 -v4
```

Then, turn on the car switch and wait for the car to connect to the agent. The connection is successful, as shown in the figure below.

```
| client_key: 0x0B62A009, part
icipant_id: 0x000(1)
                                                  | create_topic
                                                                                                       | client_key: 0x0B62A009, topi
c_id: 0x000(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, publ
                                                  | create_publisher
isher_id: 0x000(3), participant_id: 0x000(1)
                                                  I create datawriter
                                                                             | datawriter created
                                                                                                      | client_key: 0x0B62A009, data
writer_id: 0x000(5), publisher_id: 0x000(3)
                                                  | create_topic
                                                                                                      | client_key: 0x0B62A009, topi
_id: 0x001(2), participant_id: 0x000(1)
                                                  | create_publisher
                                                                                                      | client_key: 0x0B62A009, publ
isher_id: 0x001(3), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, data
                                                  | create_datawriter
writer_id: 0x001(5), publisher_id: 0x001(3)
                                                  | create_topic
                                                                                                      | client_key: 0x0B62A009, topi
_id: 0x002(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, publ
                                                  | create_publisher
isher_id: 0x002(3), participant_id: 0x000(1)
                                                  | create_datawriter
                                                                                                      | client_key: 0x0B62A009, data
writer_id: 0x002(5), publisher_id: 0x002(3)
                                                                                                      | client_key: 0x0B62A009, topi
                                                  | create topic
c_id: 0x003(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, subs
                                                                             | subscriber created
criber_id: 0x000(4), participant_id: 0x000(1)
                                                  | create_datareader
                                                                                                      | client_key: 0x0B62A009, data
reader_td: 0x000(6), subscriber_td: 0x000(4)
                                                                                                      | client_key: 0x0B62A009, topi
c_id: 0x004(2), participant_id: 0x000(1)
                                                                             I subscriber created
                                                                                                      | client_key: 0x0B62A009, subs
criber_id: 0x001(4), participant_id: 0x000(1)
                                                  | create_datareader
                                                                             | datareader created
                                                                                                      | client_key: 0x0B62A009, data
reader_id: 0x001(6), subscriber_id: 0x001(4)
                                                  | create_topic
                                                                                                      | client_key: 0x0B62A009, topi
c_id: 0x005(2), participant_id: 0x000(1)
                                                                                                      | client_key: 0x0B62A009, subs
criber_id: 0x002(4), participant_id: 0x000(1)
                                                  | create_datareader
                                                                                                      | client_key: 0x0B62A009, data
```

Then reopen a terminal and enter the following command to query the currently running node:

ros2 node list



When the car is connected to the agent, a node program will be run. If the node can be queried on the virtual machine, it means that the two have achieved distributed multi-machine communication.

Note: When running any routine, the agent only needs to be started normally once. Repeatedly starting the agent will cause the agent to report an error. If you need to restart the agent

The manager needs to ensure that the last agent used is shut down before starting again.