
3. Add navigation points in app


Function operation

Continue the operation in Section 2. The connection and login operations of the vehicle will not be described here. Please refer to the documents in the previous sections.


After selecting the map and setting the initialization point successfully. Click the navigation button in the status bar, and the navigation interface will pop up on the left. As shown in the figure below.




Then click Add point, as shown in the figure below:




Wait to switch to the Add point page, then click the button in the upper right corner, and click Add point in the pop-up interface, as shown in the figure below:




Drag the circular arrow with one finger. The circular arrow is where the coordinate point to be added is. Then lift your finger and press it to adjust the position of the added point.



After adjusting the posture, lift your finger and the input point name will pop up. After filling in, click OK to save the coordinate point.



At this time, you can see that the added coordinate point has been realized in the picture.



Click the button in the upper right corner again to see the coordinate point just added in the popup box.

