

If the User Device Manager of WIN7 system displays Board CDC, as shown below.



Right-click on the Board CDC, choose to update the driver with local file, and select the folder where the pico-serial.inf driver is located in the tutorial we provided. After the update is complete, you can see the interface as shown in the figure below.

