- 1. Adjust the potentiometer to control the fan speed and the brightness of the RGB light module.
- 2. Adjust fan speed by two button. When the red button is pressed, the fan wind speed increases by 1 and the maximum speed is 100. When the green button is pressed, the fan wind speed decreases by 1 and the minimum speed is 0.

## **Reference answer:**

For the code of this course, please refer to Motor Fan Expand\_1.sb3, Motor Fan Expand\_2.sb3.