- 1. We need to make OLED display the characters sent by the serial port. For example a, b, c.
- 2. Display static pattern on OLED.
- 3. Switch static pattern on OLED.
- 4. Using OLED draw point blocks, draw line blocks to draw a custom pattern on OLED.
- 5. Replace the OLED display sensor data block with the OLED display string and OLED display digital block to display the potentiometer value.

Reference answer:

For the code of this course, please refer to OLED_Expand_1.sb3, OLED_Expand_2.sb3, OLED_Expand_3.sb3, OLED_Expand_4.sb3.