


System Boot Modes

System Boot Modes

1. BOOT DIP Switch Location
2. BOOT DIP Switch Selection

1. BOOT DIP Switch Location

The BOOT DIP switch is located on the back of the S600 development board.



2. BOOT DIP Switch Selection

For SW8 DIP switch, set to 1 for ON, set to 0 for OFF.

Reference	D12	D13	Function
SW8	OFF	ON	System image boots from NVMe
	ON	OFF	-
	ON	ON	System image boots from UFS
	OFF	OFF	System image boots from UFS

Note:

- The V0P2 version does not support NVMe boot for the time being.