

OpenClaw WebChat Interaction

OpenClaw WebChat Interaction

[Access Directly in VNC](#)

[Access from Other Hosts on the LAN](#)

- [1. Modify OpenClaw's Configuration File to Allow Other Devices on the LAN to Access OpenClaw](#)
- [2. Start Gateway](#)
- [3. Get Access Token](#)
- [4. Establish SSH Tunnel and Access on PC](#)

Access Directly in VNC

First, connect to the host terminal and enter:

```
openc1aw gateway
```

Next, we need to get the openc1aw access token. In another terminal, enter:

```
openc1aw dashboard
```

This command displays the token once. Alternatively, you can find the `~/openc1aw/openc1aw.json` file. Your token will be configured in this file.

We connect to the board's system via VNC, then open a browser and enter the link provided in the dashboard.

Access from Other Hosts on the LAN

Common issue note: Please use the latest version of Edge or Chrome browser. Other browsers may report a 4008 error.

1. Modify OpenClaw's Configuration File to Allow Other Devices on the LAN to Access OpenClaw

```
openc1aw config
```

Here we make selections as shown in the figure below (arrow keys to select, Enter to confirm):

```
OPENCRAW
▼ OPENCRAW ▼

OpenClaw configure
Existing config detected
workspace: ~/.openclaw/workspace
gateway.mode: local
gateway.port: 18789
gateway.bind: loopback

Where will the Gateway run?
Local (this machine)

Select sections to configure
Gateway
Gateway port
18789
Gateway bind mode
LAN (All interfaces)
Gateway auth
Token
Tailscale exposure
Off
Gateway token source
Generate/store plaintext token
Gateway token (blank to generate)
7814b
Config overwrite: /root/.openclaw/openclaw.json (
p:/root/.openclaw/openclaw.json.bak)
Updated ~/.openclaw/openclaw.json

Select sections to configure
• Workspace (set workspace + sessions)
  • Model
  • Web tools
  • Gateway
  • Daemon
  • Channels
  • Skills
  • Health check
  • Continue
```

Except for the Token field which can be different from ours, everything else should be the same. The key point is the Gateway bind mode item. We need to set it to LAN to allow other devices on our local network to access our OpenClaw.

Finally, we select Continue to confirm and press Enter. Configuration is complete!

```
Select sections to configure
  • Workspace
  • Model
  • Web tools
  • Gateway
  • Daemon
  • Channels
  • Skills
  • Health check
  • Continue (Done)
```

2. Start Gateway

After completing configuration, we first start the OpenClaw Gateway. Let's open another terminal and enter:

```
openclaw gateway
```

3. Get Access Token

This Token is the one generated in our configuration. If you didn't record it, you can use:

```
openclaw dashboard
```

This command displays the token once. Alternatively, you can find the `~/.openclaw/openclaw.json` file. Your token will be configured in this file.

4. Establish SSH Tunnel and Access on PC

On a PC in the same local network, configure the environment to connect to RDK.

We open the Cmd terminal on the computer (taking Windows PC as an example: press Win+R to wake up the quick RUN tool, enter cmd, then press Enter).

In the console, enter:

```
ssh -L 18789:127.0.0.1:18789 sunrise@<sunrise-ip-address>
```

Note: Replace `<sunrise-ip-address>` with the actual IP address of your RDK board.

After pressing Enter here, you need to enter a password (default: sunrise).

We open the PC's browser and enter the IP+token string in the address bar.