

OpenClawWebChat Interaction

OpenClawWebChat Interaction

Direct Access via VNC

Access from Other Hosts on the Local Network

1. Modify OpenClaw configuration file to allow other devices on the internal network to access OpenClaw
2. Start Gateway
3. Get Access Token
4. Establish SSH Tunnel on PC and Access

Direct Access via VNC

First, connect to the host terminal and enter:

```
openclaw gateway
```

Next, we need to get the OpenClaw access token. In another terminal, enter:

```
openclaw dashboard
```

This command displays the token once, or you can find the `~/openclaw/openclaw.json` file where your token will be configured.

Connect to the board's system via VNC, then open a browser and enter the URL provided in the dashboard.

Access from Other Hosts on the Local Network

Common issue note: Please use the latest version of Edge or Chrome browser. Other browsers may encounter error 4008.

1. Modify OpenClaw configuration file to allow other devices on the internal network to access OpenClaw

```
openclaw config
```

Here we select according to the image below (use arrow keys to select, press Enter to confirm)

```
OPENCRAW
▼ OPENCRAW ▼

OpenClaw configure
Existing config detected
workspace: ~/.openclaw/workspace
gateway mode: local
gateway port: 18789
gateway bind: loopback

Where will the Gateway run?
Local (this machine)

Select sections to configure
Gateway
Gateway port
18789
Gateway bind mode
LAN (All interfaces)
Gateway auth
Token
Tailscale exposure
Off
Gateway token source
Generate/store plaintext token
Gateway token (blank to generate)
7814b
Config overwrite: /root/.openclaw/openclaw.json (
p:/root/.openclaw/openclaw.json.bak)
Updated ~/.openclaw/openclaw.json

Select sections to configure
• Workspace (Set workspace + sessions)
  • Model
  • Web tools
  • Gateway
  • Daemon
  • Channels
  • Skills
  • Health check
  • Continue
```

Except for the Token which can be different from ours, everything else should be the same. The key point is the Gateway bind mode item, which we need to set to LAN to allow other devices on our local network to access our OpenClaw.

Finally, we select Continue to confirm and press Enter to complete the configuration!

```
Select sections to configure
  • Workspace
  • Model
  • Web tools
  • Gateway
  • Daemon
  • Channels
  • Skills
  • Health check
  • Continue (Done) ←
```

2. Start Gateway

After completing the configuration, we first run the OpenClaw gateway. Open another terminal and enter:

```
openclaw gateway
```

3. Get Access Token

The Token here is the one generated in our configuration. If you didn't save it, you can use:

```
openclaw dashboard
```

This command displays the token once, or you can find the ~/.openclaw/openclaw.json file where your token will be configured.

4. Establish SSH Tunnel on PC and Access

On a PC within the same local network, configure the connection to the Jetson environment.

Open a Cmd terminal on your computer (taking Windows as an example, press Win+R to open the RUN tool, enter cmd, then press Enter)

Enter in the console:

```
ssh -L 18789:127.0.0.1:18789 sunrise@<sunrise-ip-address>
```

Note that should be replaced with the actual IP address of your RDK board.

After pressing Enter here, you need to enter the password (default is sunrise).

Open the browser on your PC and enter the IP+token address string in the address bar.