

Application - AI-programmed Status Light Control

Verify that OpenClaw has been configured.

Enter the root environment (if OpenClaw was installed under the root directory using root privileges).

```
sudo su
```


Start the Gateway. (Typically, the Gateway starts automatically, so running this command is not required.)

```
openclaw gateway
```

Interact via the TUI terminal interface.

```
openclaw tui
```

Alternatively, open the chat interface directly, or access it via WhatsApp.



Enter the interaction command

The RDK motherboard has an onboard LED. Run the program (home/sunrise/breath.py) to make your lights move like breathing

