## Jupyter lab basic usage tutorial

Due to network issues, the installation and configuration of JupyterLab takes a long time. To this end, we have prepared a pre-configured environment image for you and set it to auto-start at boot.


## Make ROSMASTER and your computer on the same LAN

1) If our ROSMASTER is connected to the same LAN as the PC network via WIFI, we can log in directly on the PC-side Google Chrome or other browser (ROSMASTER IP address): 8888 to ROSMASTER's Jupyter Lab,

for example: http://192.168.1.244:8888

192.168.1.244 is my ROSMASTERIP address. You need to input your own IP address.


As shown below:




2) Input password. If you use image we provided, password is \*yahboom\*.




3) You will see following interface.




\4) You need to enter Yahboom\_Project directory.



\5) You will see some directory, you can enter this directory. And you can see some code.




6) You can click the Run button in the top menu bar to run the program.



img = cv2.imread('yahboom.j
#cv2.imshow('image', img)
#cv2.waitKey (0)

After running the following program, the



7) If you want to exit this program and run another program. You need to click following below. And open another program file.

