


Voice module connection (Must read)


To run the voice interaction function, you must use the AI Large Model Voice Module included in the motherboard's AI Large Model Package.

Wiring Diagram:

- Raspberry Pi 5



- RDX X5



- ORIN

