Instance Segmentation

Instance Segmentation
1、Enable Optimal Board Performance
1.1、Enable Jetson Clocks
2、Instance Segmentation: Images
Preview
3、Instance Segmentation: Video
Preview
4、Instance Segmentation: Real-Time Detection
4.1、Camera
Preview
References

This document demonstrates **Ultralytics** Instance Segmentation with Python, showing its performance on images, videos, and real-time detection.

1、Enable Optimal Board Performance

1.1、Enable Jetson Clocks

Enabling Jetson Clocks ensures that all CPU and GPU cores run at maximum frequency: **(Not required on RDK and Raspberry Pi boards)**

```
sudo jetson_clocks
```

2、Instance Segmentation: Images

Use yolo26n-seg.pt to run prediction on the images bundled with the ultralytics project.

Navigate to the code folder:


```
cd ~/MODELS/yolov26/yahboom_demo
```

Run the code:

```
python3 02.segmentation_image.py
```

Preview

Location of the images output by yolo: ~/MODELS/yolov26/assets/output/



3、Instance Segmentation: Video

Use yolo26n-seg.pt to run prediction on a video in the ultralytics project (a video not bundled with ultralytics).

Navigate to the code folder:


```
cd ~/MODELS/yolov26/yahboom_demo
```

Run the code:

```
python3 02.segmentation_video.py
```

Preview

Location of the videos output by yolo: ~/MODELS/yolov26/videos/output/



4、Instance Segmentation: Real-Time Detection

4.1、Camera

Use yolo26n-seg.pt to run prediction on the USB camera feed.

Start the camera:

```
#USB camera
ros2 launch usb_cam camera.launch.py
#Nuwa camera
ros2 launch ascamera hp60c.launch.py
```

Navigate to the code folder:


```
cd ~/MODELS/yolov26/yahboom_demo
```

Run the code: click the preview window and press the q key to terminate the program!

```
python3 02.segmentation_camera_usb.py
```

Preview

Location of the videos output by yolo: ~/MODELS/output/



References

https://docs.ultralytics.com/tasks/segment/