RobotManager User Guide

RobotManager User Guide

1. Launch Methods
2. Information Panel
3. Mapping Panel
4. Navigation Panel
5. Command Panel
6. Configuration Panel
7. Parameter Panel
8. Viewing Robot Information

- RobotManager is the accompanying operation software; it integrates a set of commonly used functions, making it convenient to quickly launch features and configure robot parameter information


1. Launch Methods

- Method 1: Launch from the SSH terminal (recommended)

> **Tip**
>
> - **It is recommended to launch from the SSH terminal, which is smoother; the VNC screen's smoothness is affected by network quality**
> - In all subsequent courses of this product, the way to launch **RobotManager** is the same. Method 1: the CLI command `robot_manage gui` (Tab completion is supported); Method 2: launch from the desktop icon in VNC. In the subsequent chapter courses, when using the **RobotManager** software, the launch methods will not be repeated

```
robot_manage gui
```


- Method 2: Launch via icon; click the VNC desktop icon



RobotManager Feature Overview


2. Information Panel

- Information Panel: you can view basic information such as the mainboard IP, image version, and devices




3. Mapping Panel

- Mapping Panel: provides one-click shortcuts for common SLAM functions such as mapping, saving maps, and road network editing. How to use them will be explained in subsequent practical features



4. Navigation Panel


- Navigation Panel: provides quick launch methods for commonly used navigation algorithms



5. Command Panel


> **Important**
>
> - RobotManager must be launched in the SSH terminal for commands to be copied to the user's computer clipboard; in the VNC remote desktop, they cannot be copied to the user's computer clipboard.
> - The document content displayed in the command panel is a Markdown-format document. You can add your own custom content or make modifications by editing the document. Document path: the `~/yahboomcar_ros2_ws/yahboomcar_ws/docs/command_sets` directory; ROSMASTER-M1PRO_zh.md and ROSMASTER-M1PRO_en.md correspond to the Chinese and English documents respectively

- Command Panel: provides the operation commands for all course cases, allowing you to quickly look up all launch commands in the tutorial cases, copy them, and start them in the terminal



6. Configuration Panel


- Configuration Panel: provides commonly used system configuration items, which will be explained when needed in each lesson's tutorial document. **Note that after modifying the configuration, you must click Save Configuration for it to take effect**





7. Parameter Panel

- Parameter Panel: provides a quick way to view all configuration parameter files, allowing you to quickly view and modify function parameters. **Note that after modifying, click Save Parameters**



- When you need to exit or close the software, exit via Ctrl+q

8. Viewing Robot Information

- Method 1: CLI command

```
robot_manage info
```

```
jetson@yahboom:~$ robot_manage info
============================================================
                  ROSMASTER M1PRO Robot Info
============================================================
Current IP:          192.168.12.72
Robot Name:          ROSMASTER M1PRO
Machine Type:        OrinNano
Domain ID:           19
Namespace:           (default)
------------------------------------------------------------
Camera :         nuwa
Lidar :          tmini
------------------------------------------------------------
```

- Method 2: Click the desktop icon

