Controller Control

Controller Control

- 1. Course Content
- 2. Preparation
 - 2.1 Content Description
 - 2.2 Start the agent
 - 2.3 Check the device
 - 2.4 Testing the Controller Input
- 3. Run the Example
 - 3.1 Start the PS2 Controller Control Node
 - 3.2 Button Control Instructions
- 4. Source Code Analysis
 - 4.1 View the Node Relationship Graph
 - 4.2 Viewing Topic Messages and Message Types
 - 4.3 Program Flowchart
 - 4.4 Source Code Analysis
 - 4.4.1 Topic Communication
 - 4.4.2 Robotic Arm Control
 - 4.4.3 Chassis Movement Control

1. Course Content

Learn to control robot movement using a PS2 controller.

After running the program, use the PS2 controller to control the robot chassis and the robotic arm.

2. Preparation

2.1 Content Description

This course uses the Jetson Orin NX as an example. For Raspberry Pi and Jetson Nano boards, you need to open a terminal and enter the command to enter the Docker container. Once inside the Docker container, enter the commands mentioned in this course in the terminal. For instructions on entering the Docker container, refer to the product tutorial [Configuration and Operation Guide] - [Entering the Docker (Jetson Nano and Raspberry Pi 5 users see here)]. For Orin and NX boards, simply open a terminal and enter the commands mentioned in this course.

2.2 Start the agent

Note: All test cases must start the docker agent first. If it has already started, there is no need to restart it

Enter the command in the car terminal:


sh start_agent.sh

The terminal prints the following information, indicating that the connection is successful:

```
| set_verbose_level
| SessionManager.hpp | establish_session
                                                                                                         | client_key: 0x0DA64EFC, topic_id: 0x000(2), participant_id: 0x000(1)
| client_key: 0x0DA64EFC, publisher_id: 0x000(3), participant_id: 0x000(1)
                             | create_topic
                                                                                                         | client_key: 0x0DA64EFC, topic_id: 0x001(2), participant_id: 0x000(1)
                             | create_topic
                              | create_datawriter
                                                                                                           client_key: 0x0DA64EFC, publisher_id: 0x002(3), participant_id: 0x000(1)
client_key: 0x0DA64EFC, datawriter_id: 0x002(5), publisher_id: 0x002(3)
                              | create publisher
                              | create topic
                                                                                                           client_key: 0x0DA64EFC, topic_id: 0x003(2), participant_id: 0x000(1)
client_key: 0x0DA64EFC, publisher_id: 0x003(3), participant_id: 0x000(1)
                              | create_topic
                                                                                                           client_key: 0x0DA64EFC, topic_id: 0x004(2), participant_id: 0x000(1)
                               create_datawriter
                                                                                                         | cllent_key: 0x0DA64EFC, publisher_id: 0x005(3), participant_id: 0x000(1)
| cllent_key: 0x0DA64EFC, datawriter_id: 0x005(5), publisher_id: 0x005(3)
                              | create publisher
                              | create topic
```

2.3 Check the device


First, insert the wireless handle USB receiver into the main control (jetson, Raspberry Pi, PC), open the terminal, and enter the following command. If [js0] is displayed, it is the wireless handle. In special cases, you can also check the changes in the device list by connecting and disconnecting the wireless handle USB port. If there is a change, the changed device is the device; otherwise, the connection is unsuccessful or cannot be recognized.



2.4 Testing the Controller Input

Open Terminal and enter the following command. As shown in the image, this wireless controller has 8 axis inputs and 15 button inputs. You can test the corresponding numbers by pressing each button individually.

sudo jstest /dev/input/js0



If jstest is not installed, run the following command:

```
sudo apt-get install joystick
```

3. Run the Example

3.1 Start the PS2 Controller Control Node

Note:

• The Jetson Nano and Raspberry Pi series controllers must first enter the Docker container (see the [Docker Course Chapter - Entering the Robot's Docker Container] for steps).

Open two terminals on the car computer and run the following two nodes respectively.

Run the controller receiving node:

```
ros2 launch yahboomcar_ctrl yahboomcar_joy_launch.py
```

Run the robot controller control node:

```
ros2 run yahboomcar_ctrl yahboom_joy_M3Pro
```

3.2 Button Control Instructions

Controller Actions	Functions
Left Joystick Up/Down	Car Moves Forward/Backward
Left Joystick Left/Right	Car Moves Straight Left/Right
Right Joystick Left/Right	Car Rotates Left/Right
"START" Button	End Sleep
Left Joystick Pressed	Adjust X/Y Axis Speed
Right Joystick Pressed	Adjusting Angular Velocity
Up Button	Servo 4 Up
Down Button	Servo 4 Down
Left Button	Servo 3 Down
Right Button	Servo 3 Up
X Button	Servo 1 Left
B Button	Servo 1 Right
Y Button	Servo 2 Up
A Button	Servo 2 Down
Left "1" Button	Servo 6 Clamp (Tighten) / Servo 5 Turn Right
Left "2" Button	Servo 6 Clamp (Loose) / Servo 5 Turn Left
SELECT Button	Switching Control Between Servo 6 and Servo 5

4. Source Code Analysis

Source Code Path:

Jetson Orin Nano, Jetson Orin NX:

 $/home/jetson/yahboomcar_ws/src/yahboomcar_ctrl/yahboomcar_ctrl/yahboomcar_ctrl/yahboomcar_ioy_M3Pro.py$

Jetson Orin Nano, Raspberry Pi:


You need to enter Docker first.

root/yahboomcar_ws/src/yahboomcar_ctrl/yahboomcar_ctrl/yahboom_joy_M3Pro.py

4.1 View the Node Relationship Graph

Open a terminal and enter the command:

ros2 run rqt_graph rqt_graph



In the above node relationship graph:

• joy_node: Receives data from the controller receiver and publishes it to the /joy topic.

joy_ctrl: Subscribes to data from the **/joy** topic and parses keystrokes and corresponding operations. Publishes to the **/cmd_vel** and **/**arm_joint** topics to control the robot chassis and robotic arms.

4.2 Viewing Topic Messages and Message Types

Open a terminal on the vehicle or virtual machine and enter the following command:

ros2 interface show sensor_msgs/msg/Joy

```
jetson@yahboom: ~
          jetson@yahboom: ~
                                                   jetson@yahboom: ~
                                                                                           jetson@yahboom: ~
jetson@yahboom:~$ ros2 topic info /joy
Type: sensor_msgs/msg/Joy
Publisher count: 1
Subscription count: 1
 etson@yahboom:~$ ros2 interface show sensor_msgs/msg/Joy
 Reports the state of a joystick's axes and buttons.
 The timestamp is the time at which data is received from the joystick. td\_msgs/Header\ header
         builtin_interfaces/Time stamp
                  int32 sec
                  uint32 nanosec
         string frame_id
 The axes measurements from a joystick.
 loat32[] axes
 The buttons measurements from a joystick.
int32[] buttons
jetson@yahboom:~$
```


The data in the /joy topic is a float32 array containing timestamps.


- float32[] axes: Input data for 8 axes
- int32[] buttons: Input data for 15 buttons


4.3 Program Flowchart

Image size is too large. The original image can be viewed in this lesson's folder.









4.4 Source Code Analysis

Jetson Orin Nano and Jetson Orin NX series motherboards, source code is located here:

/home/jetson/yahboomcar_ws/src/yahboomcar_ctrl/yahboomcar_ctrl/yahboom_joy_M3Pro
.py

jetson Nano, Raspberry Pi series controller:

You need to first enter the Docker container. The source code is located here:

```
/root/yahboomcar_ws/src/yahboomcar_ctrl/yahboomcar_ctrl/yahboom_joy_M3Pro.py
```

4.4.1 Topic Communication

```
self.pub_cmdVel = self.create_publisher(Twist,'cmd_vel', 1)
self.pub_SingleTargetAngle = self.create_publisher(ArmJoint, "arm_joint", 1)
self.sub_Joy = self.create_subscription(Joy,'joy', self.buttonCallback,10)
```

The chassis and robotic arm movements are controlled by publishing topics /cmd_vel and /arm_joint, and the /joy** topic is subscribed to obtain the button status of the PS2 controller.

The essential principle of controlling the robot with a controller is to first parse the controller data, convert it into corresponding control state variables, and send it to the chassis control board via topic communication. The chassis control board subscribes to the topic data and converts it into values for directly controlling the hardware.

4.4.2 Robotic Arm Control

The function of controlling the robotic arm with a PS2 controller is implemented through the arm_ctrl method in the JoyTeleop class:

```
def arm_ctrl(self, id, direction):
   while 1:
        if self.loop_active:
            self.arm_joints[id - 1] += direction
            if id == 5:
                if self.arm_joints[id - 1] > 270: self.arm_joints[id - 1] = 270
                elif self.arm_joints[id - 1] < 0: self.arm_joints[id - 1] = 0</pre>
            elif id == 6:
                if self.arm_joints[id - 1] >= 180: self.arm_joints[id - 1] = 180
                elif self.arm_joints[id - 1] <= 30: self.arm_joints[id - 1] = 30</pre>
            else:
                if self.arm_joints[id - 1] > 180: self.arm_joints[id - 1] = 180
                elif self.arm_joints[id - 1] < 0: self.arm_joints[id - 1] = 0</pre>
            self.arm_joint.id = id
            self.arm_joint.joint = int(self.arm_joints[id - 1])
            self.arm_joint.time = 500
            self.pub_SingleTargetAngle.publish(self.arm_joint)
        else: break
        sleep(0.03)
```

4.4.3 Chassis Movement Control

Chassis movement control with the PS2 controller is implemented using the user_jetson method in the JoyTeleop class:

```
def user_jetson(self, joy_data):
    #arm_ctrl_start
    if joy_data.buttons[10] == 1: self.gripper_active = not self.gripper_active
    if joy_data.buttons[0] == joy_data.buttons[1] == joy_data.buttons[
```

```
6] == joy_data.buttons[3] == joy_data.buttons[4] == 0 and joy_data.axes[
        7] == joy_data.axes[6] == 0 and joy_data.axes[5] != -1: self.loop_active
= False
   else:
        if joy_data.buttons[3] == 1:
            print("1,-")
            self.pub_armjoint(1, -1) # X
        if joy_data.buttons[1] == 1:
            self.pub_armjoint(1, 1) # B
            print("1,+")
        if joy_data.buttons[0] == 1:
            self.pub_armjoint(2, -1) # A
            print("2,-")
        if joy_data.buttons[4] == 1:
            self.pub_armjoint(2, 1) # Y
            print("2,+")
        if joy_data.axes[6] != 0:
            self.pub_armjoint(3, -joy_data.axes[6]) # 左按键左正右负 Left button
left positive right negative
            print("3,-/+")
        if joy_data.axes[7] != 0:
            self.pub_armjoint(4, joy_data.axes[7]) # 左按键上正下负 Left button up
positive down negative
           print("4,-/+")
        if self.gripper_active:
            if joy_data.axes[5] == -1:
                self.pub_armjoint(6, -1) # L2
                print("6,-")
            if joy_data.buttons[6] == 1:
                self.pub_armjoint(6, 1) # L1
                print("6,+")
        else:
            if joy_data.axes[5] == -1:
                self.pub_armjoint(5, -1) # L2
                print("5,-")
            if joy_data.buttons[6] == 1:
                self.pub_armjoint(5, 1) # L1
                print("5,+")
    #arm_ctrl_end
    #cancel nav
    if joy_data.buttons[9] == 1:
        #print("----")
        self.cancel_nav()
    #RGBLight
    if joy_data.buttons[7] == 1:
        return
    #Buzzer
    if joy_data.buttons[11] == 1:
        Buzzer_ctrl = UInt16()
        if self.Buzzer_active == 0:
            self.Buzzer_active = self.Buzzer_active + 1
        else:
            self.Buzzer_active = self.Buzzer_active - 1
        Buzzer_ctrl.data =self.Buzzer_active
        for i in range(3): self.pub_Buzzer.publish(Buzzer_ctrl)
    #linear Gear control
    if joy_data.buttons[13] == 1:
```

```
if self.linear_Gear == 1.0: self.linear_Gear = 1.0 / 3
        elif self.linear_Gear == 1.0 / 3: self.linear_Gear = 2.0 / 3
        elif self.linear_Gear == 2.0 / 3: self.linear_Gear = 1
    # angular Gear control
    if joy_data.buttons[14] == 1:
        if self.angular_Gear == 1.0: self.angular_Gear = 1.0 / 4
        elif self.angular_Gear == 1.0 / 4: self.angular_Gear = 1.0 / 2
        elif self.angular_Gear == 1.0 / 2: self.angular_Gear = 3.0 / 4
        elif self.angular_Gear == 3.0 / 4: self.angular_Gear = 1.0
    xlinear_speed = self.filter_data(joy_data.axes[1]) * self.xspeed_limit *
self.linear_Gear
    #ylinear_speed = self.filter_data(joy_data.axes[2]) * self.yspeed_limit *
self.linear_Gear
   ylinear_speed = self.filter_data(joy_data.axes[0]) * self.yspeed_limit *
self.linear_Gear
    angular_speed = self.filter_data(joy_data.axes[2]) *
self.angular_speed_limit * self.angular_Gear
    if xlinear_speed > self.xspeed_limit: xlinear_speed = self.xspeed_limit
    elif xlinear_speed < -self.xspeed_limit: xlinear_speed = -self.xspeed_limit</pre>
    if ylinear_speed > self.yspeed_limit: ylinear_speed = self.yspeed_limit
    elif ylinear_speed < -self.yspeed_limit: ylinear_speed = -self.yspeed_limit</pre>
    if angular_speed > self.angular_speed_limit: angular_speed =
self.angular_speed_limit
    elif angular_speed < -self.angular_speed_limit: angular_speed = -</pre>
self.angular_speed_limit
   twist = Twist()
    twist.linear.x = xlinear_speed
   twist.linear.y = ylinear_speed
   twist.angular.z = angular_speed
   if self.Joy_active == True:
        print("joy control now")
        for i in range(3): self.pub_cmdVel.publish(twist)
```