# 5. Voice control robotic arm garbage identification and sorting

### 5.1. Function description

Through interaction with the voice module, rosmaster can identify and classify the junk pictures on the prescription blocks and broadcast the recognition and classification results by voice; then the robot arm will pick up the identified blocks, navigate to the set area autonomously, and put them down, and finally returns to the set origin.

#### 5.2. Start

Note: Due to the processing speed of nano master, loading model data and image processing will be a little stuck but it can still run successfully. NX master will be better.

#### 5.2.1. Function package path

```
~/yahboomcar_ws/src/garbage_identify_yolov11/
```

#### 5.2.2. Start

Note: **Multi-machine communication configuration** needs to be implemented between rosmaster X3Plus and the virtual machine. You can view the content of **"yahboomcar Course\06, Linux Operating System\04. Multi-machine Communication Configuration"** for configuration.

```
#rosmaster X3Plus start
#You need to enter docker first, perform this step more
#If running the script to enter docker fails, please refer to 07.Docker-orin/05,
Enter the robot's docker container
~/run_docker.sh
roslaunch yahboomcar_voice_ctrl voice_transport_base.launch
```

#### <Open another terminal and enter the same docker container</p>

1. In the above steps, a docker container has been opened. You can open another terminal on the host (car) to view:

2. Now enter the docker container in the newly opened terminal:

```
jetson@ubuntu:~$ docker ps -a
CONTAINER ID IMAGE COMMAND CREATED STATUS PORTS NAMES
5b698ea10535 yahboomtechnology/ros-foxy:3.3.9 "/bin/bash" 3 days ago Up 9 hours

my_robot_type: x3 | my_lidar: a1 | my_camera: astrapro

root@ubuntu:/#
```

After successfully entering the container, you can open countless terminals to enter the container.

roslaunch yahboomcar\_voice\_ctrl voice\_transport\_base.launch
rosrun garbage\_identify\_yolov11 garbage\_identify\_yolov11.py


#### <Open the host terminal (outside the docker environment)</p>

python3 /home/jetson/ultralytics/ultralytics/yahboom\_demo/garbage\_ros.py

Run the following command on the virtual machine:

roslaunch arm\_color\_transport transport\_rviz.launch

Each tool annotation on the virtual machine rviz is as shown in the figure below,




Step 1
 In rviz, use tool 1 to calibrate and position the rosmaster;

• Step 2

In rviz, use the 3 tool to mark the origin of the rosmaster. This origin is the position where the car automatically returns after putting down the color block;

• Step 3

In rviz, use 4 tools to mark red, green, blue and yellow destinations on the map in sequence. After the rosmaster's robotic arm gripper picks up the color block, it will navigate to the destination corresponding to the color of the color block. It is best to mark four points in a row here, and the front and back distance should not be too far apart, otherwise, when planning the path, you may hit the color block.



Note: **Hazardous garbage** corresponds to the **Red** marking point; **Wet garbage** corresponds to the **Green** marking point; **Recyclable garbage** corresponds to the **Blue** marking point; **dry garbage** corresponds to the **yellow** marking point.

#### • Step 4

Say "Hello, Xiaoya" to rosmaster. After waking up the voice module, place the color block about 20cm away from the camera on the robotic arm. When the object appears stably in the screen, say to it "What kind of garbage is this?" It will answer the name and type of garbage it recognizes, and after the second beep, hand the block to the gripper of the robotic arm, which will clamp the block. After rosmaster moves back to adjust its attitude, it will autonomously navigate to the previously set location. After arriving, it will put down the block with its paws and announce "Placement completed". Then, after moving back and adjusting the position, it will navigate back to the set origin and wait for the next recognition.

Note: After running the program, this screen will appear. If the label can be recognized, it means that the model has been loaded successfully.



#### 5.2.3. Core code garbage\_identify\_yolov11.py

• Code path

docker: ~/yahboomcar\_ws/src/garbage\_identify\_yolov11

- Core code analysis
  - 1) Import the corresponding library file

from Speech\_Lib import Speech #Voice recognition library
from garbage\_library import GarbageTransport #Handling navigation library

2) Create object

spe = Speech() #Create speech recognition objects
self.garbage\_transbot = GarbageTransport() #Create a handling navigation
object

- 4) Garbage\_identify\_yolov11.py mainly handles the following work:
  - Subscribe to the DetectMsg topic data, receive the recognition results, and execute the process function in the callback function.
  - o process: In this function, it mainly determines the value of the DetectMsg topic data (frame\_id), which is the name of the garbage. Then, it enters the self.garbage\_transbot.process() function. This function takes parameters. The meaning of the parameters is to go to the points marked on rviz.
- 5) garbage\_transbot.process() function

After entering this function, the current mode state will be determined first. If it is the default Grip state, the passed parameter value will be determined. 1 represents the red mark point, 2 represents the green mark point, 3 represents the blue mark point, and 4 Indicates a yellow marker. For other statuses, you can view the source code of the program. It can be seen that every time the program in this state is executed, the mode state will be changed to the next state expected to be executed.

#### 5.2.4, core code garbage\_ros.py

• Code path

Host: /home/jetson/ultralytics/ultralytics/yahboom\_demo/garbage\_ros.py #yolov11
model recognition program

## 5.3. Program node communication

rosrun rqt\_grapf rqt\_graph