Get real-time temperature of Raspberry Pi

Get real-time temperature of Raspberry Pi
- environment
- Ideas
- Get temperature parameters
- actual effect

Enter the command through the terminal to check the current CPU temperature of the Raspberry Pi.

environment

System: Raspberry Pi OS

```
Raspbian is the old name of Raspberry Pi's official Debian-based operating
system, and Raspberry Pi OS is its new name after its name change in 2020.
```

Ideas

The CPU temperature information of the Raspberry Pi is located in the file /sys/class/thermal/thermal_zone0/temp, which is a read-only file; we can read the value and convert it to the actual temperature.

Get temperature parameters

Open the terminal and run the following two commands to obtain the temperature parameters:

```
cd /sys/class/thermal/thermal_zone0
cat temp
```

$$T_{actualtemperature} = \frac{temperatureparameter}{1000}$$

actual effect


pi@raspberrypi: /sys..
19:36
pi@raspberrypi: /sys/class/thermal/thermal_zone0
File Edit Tabs Help
pi@raspberrypi:~ $ cd /sys/class/thermal/thermal_zone0
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
57300
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
56200
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
56750
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
57300
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
56750
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
57300
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
56750
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
57300
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
56750
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $ cat temp
56750
pi@raspberrypi:/sys/class/thermal/thermal_zone0 $