Environment Setup

Environment Setup

References
Update system environment
Install IMX500 firmware

Restart the system

Camera preview

Using our system image does not require installing or updating any software, just run the camera startup command!

References


Official website of Raspberry Pi Al Camera

https://www.raspberrypi.com/documentation/accessories/ai-camera.html

Update system environment

Make sure Raspberry Pi runs the latest software:

sudo apt update && sudo apt full-upgrade



Install IMX500 firmware

Firmware is required to start the camera:

sudo apt install imx500-all

Restart the system


Restart the system, and the previous operations will take effect:

sudo reboot

Camera preview

• Check the camera device number

ls /dev/video*




• Check the camera screen

Preview the screen for 5 seconds:

rpicam-hello

Continue to preview the screen:



Press Ctrl+c in the terminal or click the x in the upper right corner of the screen to close the program.