

Make Raspblock car and your computer in the same LAN.

1) If our Raspblock car is connected to the same LAN as the PC network via WIFI, we can log in directly on the PC-side Google Chrome or other browser (Raspblock IP address): 8888 to Raspblock's Jupyter Lab,

for example: http://192.168.1.244:8888

192.168.1.244 is my Raspblock car IP address. You need to input your own IP address.


As shown below:



2) Input password. If you use image we provided, password is yahboom.




3) You will see following interface.






4) You need to enter Yahboom_Project directory.




5) You will see some directory, you can enter this directory. And you can see some code.



6) You can click the Run button in the top menu bar to run the program.





7) If you want to exit this program and run another program. You need to click following below. And open another program file.



