The APP remote control process has been enabled by default in the image we provided.

If you need to run other routines separately, please close the APP remote control process as follows

1.Input following command to view APP remote control process.

ps -ef|grep Yahboom_Raspblock

2. You will see two process numbers of **Yahboom_Raspblock.pyc**, for example my process number is 1089,1115.

Everyone process number is different.

As shown below.

3.Input following command to kill Yahboom_Raspblock.pyc process.

sudo kill -9 1089 1115

4. Then, you can input ps -ef | grep Yahboom_Raspblock again.

You can see two Yahboom_Raspblock.pyc process is disappeared.

5. Finally, you can run others code.