Color Recognition

Color Recognition

Device connection

Hardware connection

Software connection

Color recognition module

Digital tube installation

Code analysis

Experimental results

Use Arduino Uno to drive the color recognition module to identify the three color values of the object.

Device connection

Hardware connection


Use Type-B data cable to connect Arduino Uno and computer.

Software connection

Open the "Arduino IDE" software and select the model and serial port number corresponding to the development board.

Color recognition module


The driver chip used by the color recognition module is ZC-CLS381.



Function pin	Function
VCC	Power supply interface: can be connected to 3.3V, 5V
SDA	I2C data transmission interface
SCL	I2C timing transmission interface
GND	Ground interface

Digital tube installation

We use it with a car here. You can directly use the PH2.0 interface cable that comes with the color recognition module to connect the car expansion board.



Code analysis

Here is only a brief introduction to the code content. For detailed code, please refer to the corresponding code file, which is provided in the download area!

• Include Wire library

```
#include <wire.h> // 包含用于I2C通信的库 Include Wire library
```

• Define I2C Device Address

```
#define I2C_ADDR 0x53 // 定义I2C设备地址 Define I2C Device Address

// 定义RGB三色值变量 Defines an RGB three-color value variable
unsigned int Red = 0;
unsigned int Green = 0;
unsigned int Blue = 0;
unsigned int val_red = 0;
unsigned int val_green = 0;
unsigned int val_blue = 0;
```

• Configure the color recognition module

```
* @brief 配置颜色识别模块 Configure the color recognition module
* @param None
* @retval None
void setColorRecognition(void) {
 Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
 Wire.write(0x00);
 Wire.write(0x06);
 Wire.endTransmission(); // 发送结束信号 End of transmission signal
 Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
 Wire.write(0x04);
 Wire.write(0x41);
 Wire.endTransmission(); // 发送结束信号 End of transmission signal
 Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
 Wire.write(0x05):
 Wire.write(0x01);
 Wire.endTransmission(); // 发送结束信号 End of transmission signal
```

• Gets RGB tri-color values

```
/**
* @brief 获取颜色识别模块三色值 Gets RGB tri-color values
```

```
* @param None
  * @retval None
  */
 void getColorValue() {
  int index = 0:
  char ColorData[6] = { 0 };
  // 获取红色数据 Get red data
   Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
   Wire.write(0x10);
   Wire.endTransmission();
                                  // 发送结束信号 End of transmission signal
   Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
   Wire.requestFrom(I2C_ADDR, 2);  // request 1 bytes from slave device #2
   while (Wire.available())
                                  // slave may send less than requested
    char ff = Wire.read(); // receive a byte as character
    ColorData[index] = ff;
    index++;
   }
   Wire.endTransmission(); // 发送结束信号 End of transmission signal
   // 获取绿色数据 Get green data
   Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
   Wire.write(0x0D):
   Wire.endTransmission();
                                  // 发送结束信号 End of transmission signal
   Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
  char ff = Wire.read(); // receive a byte as character
    ColorData[index] = ff;
    index++:
   }
   Wire.endTransmission(); // 发送结束信号 End of transmission signal
   // 获取蓝色数据 Get blue data
   Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
   Wire.write(0x13);
   Wire.endTransmission();
                                  // 发送结束信号 End of transmission signal
   Wire.beginTransmission(I2C_ADDR); //发送开始信号 Send the start signal
   wire.requestFrom(I2C_ADDR, 2); // request 1 bytes from slave device #2
   while (Wire.available())
                                  // slave may send less than requested
    char ff = Wire.read(); // receive a byte as character
    ColorData[index] = ff;
    index++;
   Wire.endTransmission(); // 发送结束信号 End of transmission signal
   Red = ((unsigned int)(ColorData[1] & 0xff) << 8 | (ColorData[0] & 0xff));</pre>
   Green = ((unsigned int)(ColorData[3] & 0xff) << 8 | (ColorData[2] & 0xff));</pre>
   Blue = ((unsigned int)(ColorData[5] & 0xff) << 8 | (ColorData[4] & 0xff));</pre>
   // 打印未处理的颜色数据 Print unprocessed color data
   // Serial.println(Red);
   // Serial.println(Green);
   // Serial.println(Blue);
  // 颜色校准:分别使用不同颜色的色块进行校准,将下面参数修改成红、绿、蓝对应的数值
   // Color calibration: Use color blocks of different colors for calibration, and modify the following
 parameters to the corresponding values of red, green and blue
  if (Red > 4000) Red = 4000;
  if (Green > 7000) Green = 7000;
  if (Blue > 4500) Blue = 4500;
   val_red = map(Red, 0, 4000, 0, 255);
   val\_green = map(Green, 0, 7000, 0, 255);
   val_blue = map(Blue, 0, 4500, 0, 255);
   Serial.println("RGB three color values:");
   Serial.print("R:");
   Serial.println(val_red);
   Serial.print("G:");
   Serial.println(val_green);
```

```
Serial.print("B:");
Serial.println(val_blue);
}
```

• Initialization Code

• Looping code

```
void loop() {
   getColorValue(); // 获取颜色识别模块三色值 Gets RGB tri-color values
   delay(500); // Delay 500 ms
}
```

Experimental results

After compiling the program successfully, upload the code to the Arduino Uno development board.

After the program is started, the color recognition module prints the three-color values of the current recognized object every 500 milliseconds. The object needs to be close to the color recognition module to be recognized more accurately.

The burning program cannot use other programs to occupy the serial port or external serial communication module (for example: WiFi camera module), otherwise the program cannot be burned or an error message will be prompted!