

USB Device Connection

USB Device Connection

1. Direct Connection to Motherboard USB Port
2. Connect to Motherboard USB Port via Extension Cable

There are two ways to connect the 4G module via USB. The first is to directly connect to the motherboard's USB port, and the second is to connect to the motherboard's USB port through a USB extension cable.

Before connecting to the motherboard, please confirm that the 4G module has been inserted with a usable Nano-SIM card.

Here we take Raspberry Pi USB port connection as an example, other motherboards are similar.

1. Direct Connection to Motherboard USB Port



2. Connect to Motherboard USB Port via Extension Cable

