## **Battery of STM32 Visual Tracking robot car use precautions:**

The STM32 Visual Tracking car is powered by a 11.1V 3S model power lithium battery pack.

## **Charging method:**

- 1. First, power on the charger. At this time, the three indicators turn from red to green, and the charger works normally.
- 2. Connect the battery pack to the 4Pin interface. At this time, all three indicators turn red and charge the battery.
- 3. When the three indicator lights turn green, the lithium battery pack is fully charged.

