# 12. Mediapipe arm attitude control robotic arm

12. Mediapipe arm attitude control robotic arm

12.1. Use

12.2. Principle of realization

12.3.Core code analysis PoseArm.py

### 12.1. Use

After the program is started, the camera captures the image and lifts the right arm. After the buzzer is not heard, the robotic arm will synchronously imitate the movement of the forearm (straighten, bend and close the palm).

Note: [R2] on the remote control handle has the [pause/start] function for this gameplay.

Function package path: ~/transbot\_ws/src/arm\_mediapipe/

jetson motherboard/Raspberry Pi 4B

Robot side

roslaunch arm\_mediapipe mediaArm.launch # robot

Virtual machine side (recommended)

rosrun arm\_mediapipe PoseArm.py

#### Raspberry Pi 5


Before running, please confirm that the large program has been permanently closed

Enter docker

Note: If there is a terminal that automatically starts docker, or there is a docker terminal that has been opened, you can directly enter the docker terminal to run the command, and there is no need to manually start docker

Start docker manually

./run\_docker.sh



roslaunch arm\_mediapipe mediaArm.launch


Virtual machine side (recommended)

```
rosrun arm_mediapipe PoseArm.py
```


After the program is started, press the R2 button on the handle to turn on the function. Stand in front of the camera so that the entire arm appears in the screen. At this time, the buzzer will sound. This is written in the program to prevent the robotic arm from returning after the arm is put down. Follow the movement, causing confusion in the program. We raise our elbows and wait for the buzzer to stop sounding, and the robotic arm will simulate the movement of the forearm. You can straighten or bend your wrist and open/close your palm to control the robotic arm. Remember not to move the forearm too much.

### 12.2. Principle of realization

MediaPipe Hands infers 3D coordinates of 21 hand-valued joints from one frame



The landmark model in MediaPipe Pose predicts the location of 33 pose coordinates (see figure below).



In this program, all we need is the coordinates of the part of the right arm. By calculating the angle formed by these coordinates, we can calculate how much angle each steering gear of the robotic arm needs to turn.

# 12.3.Core code analysis PoseArm.py

Code reference path: ~/transbot\_ws/src/arm\_mediapipe/scripts

• Import critical libraries

```
from media_library import *
```

• Get the information of each joint of the right arm

```
frame, pointArray, lhandptArray, rhandptArray =
self.pose_detector.findHolistic(frame)
#This pose_detector.findHolistic function prototype is in media_library.py
```

- Here is an explanation of how the angles formed by the elbow joint, wrist joint, palm opening and closing are calculated:
  - 1) As can be seen from the above figure, the three points 13-0 (palm wrist joint)-8 (top of index finger) form the wrist joint. Therefore, the coordinate values of these three points can be obtained to calculate the angle of the wrist joint;
  - 2) As can be seen from the above figure, the three points of 4 (the top of the thumb)-0 (the palm wrist joint)-8 (the top of the index finger) form the angle of the gripper. Therefore, the coordinate values of these three points can be obtained to calculate the gripper angle at which the claw needs to be clamped;

The above-mentioned 4 key joint codes are specifically realized, you can look at the program source code.

# 12.4. Program flow chart

