Serial communication

Serial communication

- 1. Learning objectives
 - Serial communication
 - Serial working mode
- 2. Hardware Construction
- 3. Experimental steps
 - 1. Open the SYSCONFIG configuration tool
 - 2. Serial port clock configuration
 - 3. Serial port parameter configuration
 - 4. Write the program
 - 5. Compile
- 4. Program Analysis
- 5. Experimental phenomenon

1. Learning objectives

- 1. Learn the basic use of the serial port of the MSPM0G3507 motherboard.
- 2. Understand the basic knowledge of serial communication.

Serial communication

Serial communication refers to a communication method in which data is transmitted bit by bit between peripherals and computers through data signal lines, ground lines, etc., and belongs to the serial communication method.

The key parameters of serial communication include baud rate, data bit, stop bit and parity bit. In order to ensure normal communication, these parameters must be consistent between the two communicating parties.

Serial working mode

- 1. Simplex mode
- **Features**: Data can only be transmitted in one direction, the sender is responsible for sending, the receiver is responsible for receiving, and there is no reverse communication.
- Application: Applicable to scenarios where information only needs to be transmitted in one direction, such as sensor data output.

2. Full-Duplex Mode

- **Features**: Data can be transmitted in both directions at the same time, and sending and receiving do not interfere with each other.
- **Implementation**: Two data lines are required, one for sending (TX) and one for receiving (RX).
- **Application**: Commonly used in scenarios that require efficient and real-time communication, such as the interaction between computers and peripherals.

3. Half-Duplex Mode

• **Features**: Data is transmitted in both directions, but not at the same time, and must be sent and received alternately.


- **Implementation**: Sending and receiving share a communication line, and the direction is switched by timing.
- **Application**: Suitable for scenarios that do not require high real-time performance, such as walkie-talkie communication.

These three modes adapt to different communication needs and can be flexibly selected according to specific application scenarios.


2. Hardware Construction

Since the development board comes with a CH340 serial port circuit, serial port communication can be directly realized through a USB cable without an external USB to TTL module.

MSPM0G3507 main control diagram



Type-C partial schematic diagram




21	PA10	UARTO_TX [2] / SPIO_POCI [3] / I2CO_SDA [4] / TIMA1_C0 [5] / TIMG12_C0 [6] / TIMA0_C2 [7] / I2C1_SDA [8] / CLK_OUT [9]	56	18	14	15	
22	PA11	UART0_RX [2] / SPI0_SCK [3] / I2C0_SCL [4] / TIMA1_C1 [5] / COMP0_OUT [6]/ TIMA0_C2N [7] / I2C1_SCL [8]	57	19	15	16	


3. Experimental steps

This lesson uses the UART0 peripheral on the PA10 and PA11 pins, and the CH340 USB-to-serial port chip on the development board to receive serial port data sent by the host computer, and then send the data to the host computer through the serial port sending function.


1. Open the SYSCONFIG configuration tool

Create a blank project empty in CCS.





Find and open the empty.syscfg file in the left workspace of CCS.



2. Serial port clock configuration


There are three sources of serial port clock, namely:

BUSCLK: CPU clock provided by the internal high-frequency oscillator, usually the chip is set to 32MHz when it leaves the factory.


MFCLK: Only a fixed 4MHz clock can be used (refer to page 132 of the user manual). If enabled, the SYSOSC_4M branch of the clock tree needs to be configured to enable it normally.

LFCLK: The clock (32KHz) is provided by the internal low-frequency oscillator. It is valid in run, sleep, stop and standby modes. Using this clock can achieve lower power consumption.


This case uses MFCLK as the clock source of the serial port. To enable MFCLK, you need to configure the clock tree in SYSCONFIG. Find the SYSCTL option in the tab on the left side of SYSCONFIG, find Use Clock Tree in the option page and check it to enable the configuration of the clock tree.



Click the second icon on the far left of the SYSCONFIG interface to open the clock tree.




Turn on the MFCLK switch in the clock tree, as shown in the figure below, click the option block on the SYSOSC_4M branch to turn on the MFCLK clock. When 4.0000Mhz appears on the right, the setting is complete.




3. Serial port parameter configuration

In SYSCONFIG, select MCU peripherals on the left, find the UART option and click Enter. Click ADD in UART to add a group of serial port peripherals.



The configuration is consistent with the keil environment case, so it will not be explained here.



Advanced Configuration		^	
UART Mode	Normal UART Mode		
Communication Direction	TX and RX		
Oversampling	16x	-	
Enable FIFOs			
Analog Glitch Filter	Disabled	1	
Digital Glitch Filter	0		
Calculated Digital Glitch Filter	0.00 s		
RX Timeout Interrupt Counts	0		
Calculated RX Timeout Interrupt	0.00 s		
Enable Internal Loopback			
Enable Majority Voting			
Enable MSB First			
Interrupt Configuration ③		^	
Enable Interrupts	Receive	*	
Interrupt Priority	Default	*	
PinMux Peripheral and Pin Configuration		^	
UART Peripheral	Any(UART0)	•	
RX Pin	PA11/57	₩ 🙃	
TX Pin	PA10/56	▼ 🖯	

Use the shortcut keys Ctrl+S to save the configuration in the .syscfg file.

4. Write the program

After configuring the serial port, we also need to manually write the interrupt service function of the serial port. Because we have enabled the receiving interrupt of the serial port, when the serial port receives data, an interrupt will be triggered, and the interrupt service function will be executed when the interrupt is triggered. The name of the interrupt service function corresponding to each interrupt is usually fixed and cannot be modified at will, otherwise the interrupt service function will not be entered correctly. The specific name of the interrupt service function is **UARTO_IRQHandler**.

You can also see the macro definition of the serial port 0 interrupt service function in the ti_msp_dl_config.h file we generated after compilation.


```
empty.syscfg
                  C empty.c
                                c ti_msp_dl_config.h ×
 05_uart > Debug > C ti_msp_dl_config.h > ...
        */
  68
  69
  70
       /* clang-format off */
  71
  72
  73
       #define POWER_STARTUP_DELAY
                                                                                  (16)
  74
  75
  76
  77
       #define CPUCLK FREQ
                                                                               32000000
  78
  79
  80
  81
       /* Defines for UART 0 */
      #define UART_0_INST
                                                                                 UART0
       #define HART 0 TNST
     #define UART_0_INST_IRQHandler
                                                                       UART0_IRQHandler
       #define UART_0_INST_INT_IRQN
                                                                         UART0_INT_IRQn
  85
  86
      #define GPIO_UART_0_RX_PORT
                                                                                 GPIOA
  87
      #define GPIO_UART_0_TX_PORT
                                                                                 GPIOA
     #define GPIO_UART_0_RX_PIN
                                                                        DL_GPIO_PIN_11
  88
      #define GPIO_UART_0_TX_PIN
  89
                                                                        DL_GPIO_PIN_10
     #define GPIO_UART_0_IOMUX_RX
                                                                        (IOMUX_PINCM22)
  90
  91 #define GPIO_UART_0_IOMUX_TX
                                                                        (IOMUX_PINCM21)
  92 #define GPIO_UART_0_IOMUX_RX_FUNC
                                                             IOMUX_PINCM22_PF_UART0_RX
  93 #define GPIO_UART_0_IOMUX_TX_FUNC
                                                              IOMUX_PINCM21_PF_UART0_TX
  94 #define UART_0_BAUD_RATE
                                                                                (9600)
  95 #define UART_0_IBRD_4_MHZ_9600_BAUD
                                                                                   (26)
  96 #define UART 0 FBRD 4 MH7 9600 BAUD
                                                                                    (3)
```

In the empty.c file, write the following code

```
#include "ti_msp_dl_config.h"
volatile unsigned int delay_times = 0;
volatile unsigned char uart_data = 0;
void delay_ms(unsigned int ms);
void uart0_send_char(char ch);
void uart0_send_string(char* str);
int main(void)
{
   SYSCFG_DL_init();
    //清除串口中断标志 Clear the serial port interrupt flag
   NVIC_ClearPendingIRQ(UART_0_INST_INT_IRQN);
    //使能串口中断 Enable serial port interrupt
   NVIC_EnableIRQ(UART_0_INST_INT_IRQN);
   while (1)
    {
        //LED引脚输出高电平 LED pin outputs high level
        DL_GPIO_setPins(LED1_PORT, LED1_PIN_2_PIN);
        delay_ms(500);
        //LED引脚输出低电平 LED pin outputs low level
        DL_GPIO_clearPins(LED1_PORT, LED1_PIN_2_PIN);
        delay_ms(500);
   }
}
```

```
//搭配滴答定时器实现的精确ms延时 Accurate ms delay with tick timer
void delay_ms(unsigned int ms)
{
   delay_times = ms;
   while( delay_times != 0 );
//串口发送单个字符 Send a single character through the serial port
void uart0_send_char(char ch)
{
   //当串口0忙的时候等待,不忙的时候再发送传进来的字符
   // Wait when serial port 0 is busy, and send the incoming characters when it
is not busy
   while( DL_UART_isBusy(UART_0_INST) == true );
   //发送单个字符 Send a single character
   DL_UART_Main_transmitData(UART_0_INST, ch);
}
//串口发送字符串 Send string via serial port
void uart0_send_string(char* str)
{
   //当前字符串地址不在结尾 并且 字符串首地址不为空
   // The current string address is not at the end and the string first address
is not empty
   while(*str!=0&&str!=0)
   {
       //发送字符串首地址中的字符,并且在发送完成之后首地址自增
       // Send the characters in the first address of the string, and increment
the first address after sending.
       uart0_send_char(*str++);
   }
}
//滴答定时器的中断服务函数 Tick ??timer interrupt service function
void SysTick_Handler(void)
   if( delay_times != 0 )
       delay_times--;
   }
}
//串口的中断服务函数 Serial port interrupt service function
void UART_0_INST_IRQHandler(void)
{
   //如果产生了串口中断 If a serial port interrupt occurs
   switch( DL_UART_getPendingInterrupt(UART_0_INST) )
       case DL_UART_IIDX_RX://如果是接收中断 If it is a receive interrupt
           //接发送过来的数据保存在变量中 The data sent is saved in the variable
           uart_data = DL_UART_Main_receiveData(UART_0_INST);
           //将保存的数据再发送出去 Send the saved data again
           uart0_send_char(uart_data);
           break;
       default://其他的串口中断 Other serial port interrupts
           break;
   }
}
```

5. Compile



If the compilation is successful, you can download the program to the development board.

4. Program Analysis

```
• empty.c
10
     int main(void)
11
         SYSCFG DL init();
12
         //清除串口中断标志 Clear the serial port interrupt flag
13
         NVIC_ClearPendingIRQ(UART_0_INST_INT_IRQN);
14
         //使能串口中断 Enable serial port interrupt
15
         NVIC_EnableIRQ(UART_0_INST_INT_IRQN);
16
17
         while (1)
18
19
             //LED引脚輸出高电平 LED pin outputs high level
20
             DL_GPIO_setPins(LED1_PORT, LED1_PIN_2_PIN);
21
             delay_ms(500);
22
             //LED引脚輸出低电平 LED pin outputs low level
23
             DL_GPIO_clearPins(LED1_PORT, LED1_PIN_2_PIN);
24
             delay_ms(500);
25
26
27
```

Serial port interrupts must be enabled manually. The function NVIC_EnableIRQ specifies to enable a certain interrupt. Before enabling, the interrupt flag must be cleared first, otherwise the interrupt will automatically enter after enabling.

```
//串口发送单个字符 Send a single character through the serial port
    void uart0_send_char(char ch)
37
        //当串口0忙的时候等待,不忙的时候再发送传进来的字符
38
39
           // Wait when serial port 0 is busy, and send the incoming characters when it is not busy
40
       while( DL_UART_isBusy(UART_0_INST) == true );
41
       //发送单个字符 Send a single character
       DL_UART_Main_transmitData(UART_0_INST, ch);
42
43
    //串口发送字符串 Send string via serial port
45
    void uart0_send_string(char* str)
        //当前字符串地址不在结尾 并且 字符串首地址不为空
           // The current string address is not at the end and the string first address is not empty
        while(*str!=0&&str!=0)
           //发送字符串首地址中的字符,并且在发送完成之后首地址自增
                  // Send the characters in the first address of the string, and increment the first address after sending.
            uart0 send char(*str++);
55
```

Define two functions, uart0_send_char function sends a single character through the serial port, and uart0_send_string function sends a string through the serial port.

```
//串口的中断服务函数 Serial port interrupt service function
67
    void UART_0_INST_IRQHandler(void)
68
        //如果产生了串口中断 If a serial port interrupt occurs
69
        switch( DL_UART_getPendingInterrupt(UART_0_INST) )
71
            case DL UART IIDX RX://如果是接收中断 If it is a receive interrupt
72
73
               //接发送过来的数据保存在变量中 The data sent is saved in the variable
               uart_data = DL_UART_Main_receiveData(UART_0_INST);
74
               //将保存的数据再发送出去
75
76
               uart0_send_char(uart_data);
77
               break;
           default://其他的串口中断 Other serial port interrupts
79
80
            break;
81
82
```

UART_O_INST_IRQHandler function implements the function of receiving and returning data through the serial port. Get the interrupt type of the current UARTO through DL_UART_getPendingInterrupt(). If a UART interrupt triggered by data is received, the received data is saved in a variable and then sent out.

5. Experimental phenomenon

After the program is downloaded, you can send data to the development board through the serial port debugging assistant, and you can see the data returned by the development board.

