DAP-LINK download program

DAP-LINK download program

- 1. Hardware connection
- 2. Related configuration
- 3. Download the program
- 4. Common Problems

This method uses keil to burn directly. **DAP-LINK needs to be purchased by yourself.**

Note: You cannot use ST-LINK to download, the chip will be locked, and the download will display PDSC.

1. Hardware connection


DAP-LINK	MSPM0G3507
GND	GND
VDD or 3V3	3V3
SWCLK	SWCLK(PA20)
SWDIO	SWDIO(PA19)




2. Related configuration

Click the magic wand Options for Target, select the Debug column, the emulator is DAP-LINK, select CMSIS-DAP Debugger here.


Then click Setting



If the hardware is normal and the wiring is OK, a device number will automatically appear at Sw Device, indicating that the chip has been successfully identified.



Then select the Flash Download column, check Reset and Run, and select the correct chip.




After completing the above configuration, click ox and you can start downloading the code.

3. Download the program

Click Build to compile first, and then click the Download icon to start downloading after confirming that the compilation is successful




Wait for the progress bar below to complete. When Flash Load finished is displayed, it means the download is successful.




4. Common Problems

1. Error: Error: Flash Download failed - "Cortex-M0+"



Answer: Reason ①: Wiring error; Reason ②: Download algorithm not added



2. Error Cannot Load Flash Device Description!

Answer: The download algorithm has not been added. You can add it in this way:

