GPIO reading

GPIO reading

1. GPIO pin diagram
2. Run the program
3. Program effect

1. GPIO pin diagram

GPIO.BOARD 12 pin corresponds to GPIO.BCM 18 pin:



2. Run the program

```
cd ~/jetson-gpio/samples
```

```
export JETSON_MODEL_NAME=JETSON_ORIN_NX
```

```
python3 simple_input.py
```

3. Program effect

Use Dupont wire to connect GPIO.BOARD 12 pin to GND and 3.3V pin on the motherboard, and test the reading of high and low levels:

Note: Do not connect incorrectly or cause pin short circuit, as mistakes may cause damage to the motherboard hardware!


Activities
Terminal
Jan 20 18:51
MAXN SUPER
jetson@yahboom: ~/jetson-gpio/samples
jetson@yahboom:~$ cd ~/jetson-gpio/samples
jetson@yahboom:~/jetson-gpio/samples$ export JETSON_MODEL_NAME=JETSON_ORIN_NX
jetson@yahboom:~/jetson-gpio/samples$ python3 simple_input.py
Starting demo now! Press CTRL+C to exit
Value read from pin 18 : LOW
Value read from pin 18 : HIGH
Value read from pin 18 : LOW
Value read from pin 18 : HIGH
Value read from pin 18 : LOW
Value read from pin 18 : HIGH
Jetson Developer Zone
Jetson Support Forums
L4T-README
Terminal
NVIDIA Jetson Community Pro...
Jetson Zoo
Home