GPIO Output Function

GPIO Output Function

1. GPIO Pin Diagram
2. Running the Program
3. Program Results

1. GPIO Pin Diagram

GPIO.BOARD pin 12 corresponds to GPIO.BCM pin 18:



2. Running the Program

Currently, the GPIO output control function is malfunctioning. Waiting for NVIDIA software to fix it!

```
cd ~/jetson-gpio/samples
```

```
python3 simple_out.py
```

3. Program Results

Using DuPont wires to bring out GPIO.BOARD pin 12 and GND pins, a multimeter can be used to measure the pin voltage changes:

Caution: Do not connect incorrectly or cause a short circuit. Errors may damage the motherboard hardware! **


Activities
Terminal
Jan 20 18:53
MAXN SUPER
jetson@yahboom: ~/jetson-gpio/samples
jetson@yahboom:~$ cd ~/jetson-gpio/samples
jetson@yahboom:~/jetson-gpio/samples$ export JETSON_MODEL_NAME=JETSON_ORIN_NX
jetson@yahboom:~/jetson-gpio/samples$ python3 simple_out.py
Starting demo now! Press CTRL+C to exit
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
Outputting 1 to pin 18
Outputting 0 to pin 18
Jetson Developer Zone
Jetson Support Forums
L4T-README
Terminal
NVIDIA Jetson Community Pro...
Jetson Zoo
Home