

Drag teaching

1 Applicable Robot Arm

- myCobot 320 M5

2 Steps

Step 1: Burn the latest **atomMain** to **Atom** .

Step 2: Burn **minirobot** for **M5Stack-basic** , then press **Maincontrol** .



Step 3: Press **Record** .



Step 4: Select the storage path and press **Ram** or **Flash** .



Step 5: Move the joints of the robot arm to a specific position. Then, press any of the three buttons to stop recording and save the action.



Step 6: Press **play** to let the robot perform the action just recorded.



Note:

Pause : Pause the movement

Stop : Stop the movement

