

Use Cases

SendOneAngle()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SendOneAngle(1,20,50); //Move a joint by 20 degrees at a speed
of 50

            Thread.Sleep(5000);
            mc.Close();
        }
    }
}
```

GetAngles()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            var recv = mc.GetAngles();//Get angle information
            foreach (var v in recv)
            {
                Console.WriteLine(v);
            }
            mc.Close();
        }
    }
}
```

```
}
```

SendAngles()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SendOneAngle(1,0, 70);
            Thread.Sleep(100);
            mc.Close();
        }
    }
}
```

GetCoords()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            var recv = mc.GetCoords();
            foreach (var v in recv)
            {
                Console.WriteLine(v);
            }
            Thread.Sleep(100);
            mc.Close();
        }
    }
}
```

```
}
```

SendCoords()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            int[] coords = new[] {160, 160, 160, 0, 0, 0}; //Parameter 1:
coordinate, 2: speed, 3: mode
            mc.SendCoords(coords, 90, 1);
            Thread.Sleep(100);
            mc.Close();
        }
    }
}
```

SendOneCoord()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SendOneAngle(1,0, 70);
            Thread.Sleep(100);
            mc.Close();
        }
    }
}
```

SetDigitalOut()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SetDigitalOut(23, 0);
            Thread.Sleep(100);
            mc.SetDigitalOut(33, 0);
            Thread.Sleep(100);
            mc.Close();
        }
    }
}
```

GetDigitalIn()

```
using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            int num = GetDigitalIn(23);
            mc.Close();
        }
    }
}
```

setGripperValue()

```
using System;
```

```

using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SetGripperMode(0);//Transparent transmission
            Thread.Sleep(1000);
            mc.setGripperValue(0,10)
            mc.Close();
        }
    }
}

```

getGripperValue()

```

using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SetGripperMode(0);//Transparent transmission
            Thread.Sleep(1000);
            int num = mc.getGripperValue();
            mc.Close();
        }
    }
}

```

SetBasicOut()

```

using System;
using System.Threading;

namespace Mycobot.csharp

```

```

{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            mc.SetBasicOut(2, 1);
            Thread.Sleep(100);
            mc.SetBasicOut(5, 1);
            Thread.Sleep(100);
            mc.SetBasicOut(26, 1);
            Thread.Sleep(100);
            mc.Close();
        }
    }
}

```

GetBasicIn()

```

using System;
using System.Threading;

namespace Mycobot.csharp
{
    class Test
    {
        static void Main(string[] args)
        {
            MyCobot mc = new MyCobot("COM57");//Raspberry Pi robotic arm
serial port name: /dev/ttyAMA0
            mc.Open();
            Thread.Sleep(5000);//After windows opens the serial port, you
need to wait for 5 seconds, and the basic button at the bottom of windows will
restart when it opens the serial port.
            int num = mc.GetBasicIn(35);
            mc.Close();
        }
    }
}

```