
Overview:


This document describes how to configure the SLA-2000-OEM for RTP MJPEG video output to JMStudio.

SLA-PANEL Setup:

- 1. **Open SLA-PANEL** and **Connect** to your SLA-2000-OEM system
- 2. Video tab \rightarrow Video Mode \rightarrow Display Dest \rightarrow Network



- 3. Ethernet Video tab \rightarrow RTP-MJPEG
- 4. **Ethernet Video t**ab \rightarrow Use My IP (should reflect the IP address of your PC)
- 5. Ethernet Video tab \rightarrow Port = 5004
- 6. **Ethernet Video** tab \rightarrow Apply



7. Close SLA-Panel

Using Native Commands:

Use the SLFIPSetVideoMode() and SLFIPSetEthernetDisplay() functions from slfip.h to programatically execute the above instructions. The hex version of the commands can also be copied from the window in the lower left corner of SLA-PANEL.

View RTP MJPEG Stream

- 8. Install JM Studio
- 9. Open **JMStudio**
- 10. Menu \rightarrow File \rightarrow Open RTP Session...
- 11. Address = IP address of PC (see step 5 above)
- 12. Port = 5004
- 13. Click Open

