R-type:

opcode[15:13] | rd[12:10] | rs1[9:7] | rs2[6:4] | func[3:0]

I-type:

opcode[15:13] | rd[12:10] | rs[9:7] | imm[6:0]

Load/Store:

Opcode[15:13] | rd/rs[12:10] | addr[9:6] | reserved[5:0]

Jump:

Opcode[15:13] | imm[12:5] | reserved[4:0]

Branch_Equal_Zero/BNEQZ

Opcode[15:13] | rs[12:10] | addr[9:2] | reserved[1:0]

Code	Name	
000	R-type	
001	I-type	
010	Load	
011	Store	
100	Jump	
101	BEZ	
110	BNEZ	
111	NOP	